



© 1977 TOYOTA MOTOR SALES CO., LTD. All rights reserved. This book may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Sales Co., Ltd.

#### FOREWORD

This repair manual describes the removal, installation, disassembly, assembly, adjustment and maintenance procedures required for servicing chassis, body components and body electrical system of the TOYOTA LAND CRUISER.

For service of the TOYOTA LAND CRUISER engines, refer to the following repair manuals:

2F Engine Repair Manual (Pub. No.98126) B Engine Repair Manual (Pub. No.98260) H Engine Repair Manual (Pub. No.98112)

Under DISASSEMBLY and ASSEMBLY, you will find disassembled views which carry numbers indicating the sequence of operation procedure. The operations can be accomplished by following these numbers. To facilitate understanding, there are also some figure numbers after operation numbers showing the locations of work details. The texts have different symbol marks which supersede the figure explanation.

The specifications and repair procedures contained herein are subject to change at any time without previous notice.

TOYOTA MOTOR SALES CO., LTD.

# SECTION INDEX

| N A M E                            | SECTION |
|------------------------------------|---------|
| GENERAL                            | 1       |
| CLUTCH                             | 2       |
| <b>TRANSMISSION &amp; TRANSFER</b> | 3       |
| PROPELLER SHAFT                    | 4       |
| REAR AXLE                          | 5       |
| FRONT AXLE                         | 6       |
| STEERING                           | 7       |
| BRAKE                              | 8       |
| FRONT WINCH                        | 9       |
| FRAME                              | 10      |
| BODY                               | 11      |
| BODY ELECTRICAL                    | 12      |
| SST & SERVICE SPECIFICATIONS       | 13      |

122211312111

URTE

page

1

# GENERAL

| GENERAL  | REPAIR | R INST | RUC         | TIONS | 5           | 1 | -2 |
|----------|--------|--------|-------------|-------|-------------|---|----|
| ABBREVIA | TIONS  | USED   | IN          | THIS  | MANUAL ···· | 1 | -3 |
| SYMBOL   | MARKS  | •••••  | • • • • • • |       |             | 1 | -4 |

.

### GENERAL REPAIR INSTRUCTIONS

- 1. Use fender, seat, and floor covers to keep the car clean and prevent damage.
- 2. During disassembly, keep parts in order for reassembly.
- 3. Before performing electrical work, disconnect the cable to the positive (+) battery terminal.
- 4. Always replace cotter pins, gaskets and O-rings with new ones.
- 5. Always use sealer on gaskets to prevent leaks.
- 6. Carefully observe all specifications for bolt torques. Always use a torque wrench.
- 7. Use genuine Toyota parts.
- 8. If the vehicle is to be jacked up only at the front or rear end, be sure to block the wheels in order to ensure safety.
- 9. After the vehicle is jacked up, do not fail to support it on stands. It is extremely dangerous to do any work on the vehicle raised on jack alone, even for a small job that can be finished quickly.
- 10. Use of a special service tool (SST) may be required, depending on the nature of the repair. Be sure to use SST where specified and follow the proper work procedure. A list of the SST is found at the back of this manual.

# ABBREVIATIONS USED IN THIS MANUAL

For convenience, the following codes are used in this manual.

| Abbreviation | Term                 | Definition  |
|--------------|----------------------|---|
| RH           | Right Hand           |   |
| LH           | Left Hand            |   |
| SST          | Special Service Tool | This term designates tools that have been<br>manufactured specially for the servicing of<br>this vehicle.<br>Their part numbers are shown in the text<br>enclosed by [ ]. |
| STD          | Standard             | This term refers to the dimension of the part when originally manufactured.   |
| O/S          | Oversize             | Sizes larger than STD are indicated as O/S.   |
| U/S          | Undersize            | Sizes smaller than STD are indicated as U/S.  |
| МР           | Multipurpose         | Use in the case of MP grease.   |
| W/           | With                 |   |
| W/O          | Without              |   |
| M/T          | Manual Transmission  |   |

# SYMBOL MARKS

The following symbols have been adapted for simplicity and for easy comprehension.

| •         | ASSEMBLY     |
|-----------|--------------|
| <b>+</b>  | DISASSEMBLY  |
| <b>*+</b> | INSTALLATION |
| <b>++</b> | REMOVAL      |
| լա        | INSPECTION   |
| Ð         | MEASUREMENT  |
| Ę         | TIGHTENING   |
|           | CLEAN        |
| $\wedge$  | IMPORTANT    |

# CLUTCH

#### page

2

| ADJUST | MENT                 |
|--------|----------------------|
| CLUTCH | PEDAL                |
| CLUTCH | MASTER CYLINDER 2-4  |
| CLUTCH | RELEASE CYLINDER 2-6 |
| CLUTCH | UNIT                 |

|                      | 1-/10. | 31250-60020    | \$46        |
|----------------------|--------|----------------|-------------|
| PRESSURE PLATE       | 12/N   | 31210-60062.   | #102        |
| THRUST BEARING       | P/N    | 90363-52086    | \$26        |
| PILOT BEARING        | P/N    | 97143-06201    | B6 00       |
| SUMP GASKET          | P/N    | 12151 - 60021  | \$12        |
| GEAR BOX INPUT SHAFT | OILS   | EAL P/N 90311- | 28004 \$3.  |
| " END PLATA          | E GASK | ET P/N 33132-  | 36010 \$1.0 |

I.





Fig. 2-3



4. Depress the clutch pedal several times, and then while holding it depressed, loosen the bleeder plug about one-third to one-half turn. When the fluid pressure in the cylinder is almost depleted retighten the plug. Repeat this operation until there are no more air bubbles in the system.

## ADJUSTMENT

#### **CLUTCH PEDAL**

- Loosen the lock nut (2) and the push rod (3).
- 2. Adjust the pedal height by turning the stop bolt (1).

#### Standard pedal height

|                     | w/brake booster<br>mm (in.) | w/o brake booster<br>mm (in.) |
|---------------------|-----------------------------|-------------------------------|
| FJ, HJ, BJ40 series | 215<br>(8.46)               | 198<br>(7.86)                 |
| FJ55 series         | 185<br>(7.28)               | 172                           |

#### (From asphalt sheet top surface)

 Adjust the pedal play by loosening the lock nut (2) and turning the push rod (3).
 Pedal play 0.5-3.0 mm (0.02-0.12 in.)

at pedal top

#### **RELEASE CYLINDER**

Adjust the play at release fork tip by loosening the lock nut (1), and turning the push rod (3) tip with a spanner while holding the push rod nut (2) with a wrench.

Fork tip play FJ, HJ series 3-4 mm (0.12-0.16 in.) BJ series 2-3.5 mm (0.08-0.14 in.)

#### BLEEDING CLUTCH SYSTEM

If any work is performed on the clutch system or if any air enters in the clutch line, remove the air by bleeding the system.

- Caution -

- 1. When bleeding make certain that the brake fluid in the master cylinder reservoir does not become empty.
- 2. Do not allow brake fluid to remain on painted surfaces.
- 1. Jack up the car and support it on stands.
- 2. Fill the master cylinder reservoir.
- 3. Attach a vinyl tube to the release cylinder bleeder plug, and insert the other end of tube into a container.
- When the bubbles stop, depress and hold the clutch pedal and tighten the bleeder plug.
- 6. After completing the bleeding operation, apply fluid pressure on the pipe line and check for leakage.
- 7. Replenish the fluid in the reservoir to the specified level.

2-2

# CLUTCH PEDAL

# CLUTCH – Clutch Pedal

VLIND!

2-3

## REMOVAL

Remove the parts in the numbered order shown in the figure.



۲

Fig. 2-5



#### INSPECTION

Inspect the removed parts for damage and wear.

#### INSTALLATION

Perform the removal in reverse order. For pedal height adjustment, refer to Adjustment.

# CLUTCH MASTER CYLINDER

#### DISASSEMBLY

Disassemble the parts in the numbered order shown in the figure.

Fig. 2-6





Inspect the master cylinder bore for wear and scoring.

Inspect the piston assembly for wear and scoring.

If the cup requires replacement, use the cylinder

Fig. 2-8



Fig. 2-9



#### ASSEMBLY

- Note -

kit.

Perform the disassembly in reverse order. - Note -

Apply rubber grease on the parts shown by arrows before assembling.

R.

# CLUTCH RELEASE CYLINDER

#### DISASSEMBLY

Disassemble the parts in the numbered order shown in the figure.





.

Fig. 2-11



#### INSPECTION

Inspect the disassembled parts for wear and damage.





#### ASSEMBLY

Perform the disassembly in reverse order.

- Note –
  1. Wash all parts in fresh brake fluid before assembling.
- 2. Pack rubber grease in the parts shown by arrows.
- 3. Adjust the release cylinder. (Refer to Adjustment.)



# CLUTCH UNIT

1. Remove the transmission and transfer.

Refer to transmission removal procedures.2. Remove the clutch cover and clutch disc.

- Note -

Use care not to get oil or grease on the clutch disc linings, or on the pressure plate and flywheel surfaces that contact on the clutch disc.

#### DISASSEMBLY

Disassemble the parts in the order numbered in the following illustrations.



.





#### [FJ Series]

Place mating marks on the clutch cover and pressure plate.

Fig. 2-17



Separate the clutch cover from the pressure plate.

- 1. With a center punch, accurately locate drill hole at the center of each rivet head.
- 2. Using a 10-mm drill (13/64 in. drill), out the rivet heads.
- Punch out the rivets and separate the clutch cover from the pressure plate.
   Note –

Make the separation with the rivets at the pressure plate side.



#### [HJ Series]

Place mating marks on the clutch cover and pressure plate.



6)

Fig. 2-18



Fig. 2-20



+**†**+

Mating Marks

Press down only the clutch cover with a press. Remove the three bolts, and separate the clutch cover from the pressure plate.

#### [BJ Series]

Place mating marks on the clutch cover and pressure plate.

Fig. 2-21



Re str

Remove the three bolts attaching the clutch straps.





Fig. 2-24



]

#### **Clutch Cover Assembly** [FJ Series]

Inspect the clutch cover and pressure plate for wear and burning, and repair or replace if found defective.

Fig. 2-25





#### [HJ Series]

Inspect the clutch cover, pressure plate, and pressure levers for wear and burning, and repair or replace all parts found defective.



#### **Clutch Disc**

**Run-out limit** 

Inspect the disc, and repair or replace if any part of it is found defective. Rivet head depth limit

Loosen the three nuts one turn each. Press down only the clutch cover.

cover from the pressure plate.

Remove the three nuts and separate the clutch

0.3 mm (0.012 in.) 1.0 mm (0.04 in.)



| Measure the installed load of each compression      |
|---|
| spring, and if below the limit, replace the spring. |

|                            | Small Spring | Large Spring |
|----------------------------|--------------|--------------|
| Installed Length (in.)     | 42.9 (1.689) | 43.5 (1.713) |
| Installed Load (Ib.)       | 42.5 (93.5)  | 62.2 (137)   |
| Installed Load Limit (Ib.) | 40 (88)      | 53 (117)     |

Fig. 2-27



E

լթ

#### [BJ Series]

Inspect the clutch cover, pressure plate, and pressure levers for wear and burning, and repair or replace all parts found defective.

Fig. 2-28



Measure the install load of each compression spring, and if below the limit, replace the spring. Installed length Installed load Installed load limit

37.1 mm (1.461 in.) 44.6 kg (98.3 lb.) 39 kg (86 lb.)

Fig. 2-29



Fork, Hub And Bearing Inspect for damage and wear. 2-11













[BJ Series]

- Note -

 $\dot{\mathbf{x}}$ 

Assemble the parts in the numbered order shown in the figure.

- 1. Apply multipurpose grease on the sliding surfaces of all parts.
- 2. Have the mating marks aligned when assembling the clutch cover to the pressure plate.
- 3. When assembling the clutch cover to pressure plate, use a press in the same manner as during disassembly.



# INSTALLATION

#### Install the Clutch Cover

Using SST [09301-55022], install the clutch disc and clutch cover to the flywheel.

- Note -

- 1. With the cover attaching bolts tightened lightly, carefully move the guide tool up and down and sideways to see that the cover is properly centered before installing.
- 2. Tighten the bolts back and forth in diagonal order, a little at a time, until tightened to specified torque.

Use care to see that the clutch disc is 3. facing in proper direction when installed.

4. Apply light coat of multipurpose grease on the splines in the disc and input shaft.





Fig. 2-38



Ð Adjustment [FJ Series]

> Inspect the clutch diaphragm for uniformity of tip heights. -

Non-uniformity limit 1.0 mm (0.04 in.)

#### [HJ Series]

m

Using SST[09302-25010], adjust the lever heights.

Specified height 14.2 mm (0.559 in.)

- Note -

After completing adjustment, make sure to tighten the lock nuts securely.

#### m Đ Using SST[09302-25010], adjust the lever heights. Specified height

# - Note -

[BJ Series]

After completing adjustment, stake the adjust nuts to prevent them from loosening.

12.0 mm (0.472 in.)

# **TRANSMISSION & TRANSFER**

#### page

3

| CUTAWAY  | VIEW           | • • • • • • • • • • • | •••••              | • • • • • • • • | З-  | 2  |
|----------|----------------|-----------------------|--------------------|-----------------|-----|----|
| 4-SPEED  | TRANSMISSION   | ( <b>H4</b> 1         | <b>&amp; H</b> 42) | ••••            | З-  | З  |
| 3-SPEED  | TRANSMISSION   | (J30                  | )                  | • • • • • • • • | 3-3 | 37 |
| TRANSFEF | <b>{</b> ····· |                       |                    |                 | 3-5 | 52 |

# CUTAWAY VIEW





# 4-SPEED TRANSMISSION (H41 & H42)

#### REMOVAL

#### **Removal From Vehicle**

- Drain out the transmission oil, transfer oil, and fuel (except FJ55 series.)
   Remove the parts in the order numbered in following illustrations.

#### Fig. 3-2



Undercover 1 2 Propeller Shafts

- Speedometer Cable 3
- 4 Parking Brake Cable

# TRANSMISSION & TRANSFER – 4-Speed Transmission (H41, H42)

## Fig. 3-3

3-4

AND



- Front Seats, Seat Frames, & Console Box 5 (Except FJ55 Series)
- Rear Heater Pipe Clamp (Except FJ55 Series) 6
- 7 Fuel Tank Cover & Fuel Tank (Except FJ55 Series)
- 8 Shift Lever Knobs
- 9
- Dust Proof Boot And Shift Lever 10
- 11 Transmission Cover



12 Front Drive Indicator Wire Harness (Magnet Type Only)

Fig. 3-4

- 13 Vacuum Hoses (Magnet Type Only)
- 14 Transfer Switch Wire Harness (Magnet Type Only)

16 Fig.3-7

17

- 15 Back Up Light Switch Wire Harness
- 16 Bolts 17
  - Transmission With Transfer

# 3–6 TRANSMISSION & TRANSFER – 4-Speed Transmission (H41, H42)



Remove the parking brake cable by disconnecting it at the parking brake lever.

Perform in the numbered order shown in the figure.

. .

Fig. 3-6



Use SST [09305-60010]

**++** 

Fig. 3-7



Remove the four bolts while using jack and rope to support the transmission with transfer.

.

#### Separate The Transfer From The Transmission.

Make the separation in the numbered order shown in the figure.







#### DISASSEMBLY

Transmission Gear And Case Disassembly

Disassemble in the order numbered in the following illustrations.

# Fig. 3-14



# 3-10 TRANSMISSION & TRANSFER – 4-Speed Transmission (H41, H42)











Fig. 3-19

Fig. 3-20

SS



SST

Use SST [09950-20010] .

**\***\*

Use SST [09905-00010].

Use SST[09905-00010]

**\*** 

**(++)** 

#### Fig. 3-21



Fig. 3-22



Fig. 3-23



**+**+

Fit the SST[09314-36010] to the tip of drive shaft and mount the SST to the case. Using SST[09950-20010] and SST[09956-00010], remove the bearing.

Drive out the input shaft assembly from the case.

Fig. 3-24



Hold the first gear tightly against the other gears and pull out the output shaft assembly from the case.

- Caution -

When pulling out the assembly, hold the gears in place to keep them from sliding off the shaft.
**\***\*



Fig. 3-26



Use SST[09905-00010].

Drive out the reverse idler gear toward the rear.

## Transmission Case Cover Disassembly

Disassemble in the numbered order shown in the figure.









| Fig. 3-39 |           | _  |
|-----------|-----------|--|
| Front     | *         | <ul> <li>5. Assemble the hub sleeve(2), three shifting keys(3) and two key springs(4) to the clutch hub(1).</li> <li>Note –</li> <li>1. Hub and hub sleeve are parts having directionality.</li> <li>2. Install the key springs positioned so that their end gaps will not be in line.</li> <li>3. Check the hub and hub sleeve to see that they slide smoothly together.</li> </ul> |
| Fig. 3-40 | E         | <ol> <li>Check the clearance between the sleeve and shift fork.</li> <li>Third-fourth and first-second<br/>Limit 0.8 mm (0.031 in.)</li> </ol>   |
| Fig. 3-41 | Jæ        | <ol> <li>Inspect the gear teeth, splines, coned surfaces, and bearing for damage and wear.</li> <li>Inspect the shaft inner surface that contact on the needle roller bearing for damage and wear.</li> </ol>  |
| Fig. 3-42 | <b>++</b> | <ol> <li>Input Shaft Bearing Replacement         <ol> <li>Remove the snap ring, using SST[09905-00010].</li> <li>Remove the bearing, using SST[09950-20010]</li> <li>Install the new bearing, using a press.</li> </ol> </li> </ol>  |

Ð

3

Fig. 3-43



Fig. 3-44



Fig. 3-45





 Select a snap ring of the thickness that will allow minimum axial play, and install it on the shaft.

Snap Ring Sizes

| Part No.             | Thickness mm (in.)            |
|----------------------|-------------------------------|
| 90520-36 <b>0</b> 15 | 3.31 - 3.42 (0.1303 - 0.1346) |
| 90520-36016          | 3.20 - 3.31 (0.1260 - 0.1303) |

#### Countergear

- 1. Inspect the countergear teeth for damage and wear.
- 2. Inspect the front and rear bearings for damage and wear,

Rear bearing inner race replacement.

- a. Using SST[09602-10010], remove the inner race.
- b. Using SST[09515-21010], install the new inner race.

– Caution –

3.

J

Make sure to position the inner race so that its flanged side will be directed toward the front.

Fig. 3-46



# Reverse Idler Gear, Bushing, And Shaft

Inspect the gear, bushing, and shaft for wear and damage.

Oil clearance limit

0.16 mm (0.0063 in.)



Fig. 3-48



Fig. 3-49



Fig. 3-50





0

ງ

#### **Reverse Idler Gear Bushing Replacement**

- Using a press and socket wrench (24 mm), 1. force out the old bushings.
- Using the same press and socket wrench, press in the new bushings respectively from the front and rear ends of the gear. – Note –

Press in the bushings until 1 mm deep from the gear end faces.

# **Reverse Shift Arm**

Inspect the shift arm shoe(1) for wear and 1. damage.

#### Shoe thickness limit 8.0 mm (0.319 in.)

- 2 Inspect the shift arm at shoe mounting part(2) and pivot mounting part(3) for wear and damage.
- З. Inspect the pivot(4) for wear and damage.
- 4. Inspect the clearance between the shoe and reverse idler gear slot.

Limit 0.70 mm (0.028 in.)

#### **Case Cover Parts**

- Inspect the shafts and shift head for wear 1. and damage at their sliding surfaces. Also, inspect the shafts for bending.
- 2. Inspect the case cover for wear and damage at the surfaces contacting on the shafts.
- Inspect the balls for damage and wear. З.
- 4. Inspect the springs for weakening.



#### **Reverse Shift Head**

- Disassemble the shift head in the numbered 1. order shown in the figure.
- 2. Reassemble by performing the disassembly in reverse order.

– Note –

- After installing the "C" washer, bend both 1. ends inward.
- 2. Verify that the plunger slides smoothly.

# 3-22 TRANSMISSION & TRANSFER – 4-Speed Transmission (H41, H42)

# ASSEMBLY

#### Transmission Case Cover Assembly

Assemble in the numbered order shown below.

#### Fig. 3-51

1





#### Transmission Gear And Case Assembly

Assemble the output shaft in the numbered order shown below.





Assemble in the numbered order shown below.



Assemble in the numbered order shown below.

- Note -

Apply gear oil to all sliding, rotating and engaging parts of the transmission, and coat liquid sealer on the gaskets and through bolts before assembling them.





♦ Alig inst

Align the bushing groove with the ball, and install the bushing to the output shaft.

3-27





Fig. 3-61



Select a snap ring of the thickness that will reduce the clearance to a minimum.

Snap Ring Thickness

| Size Mark | Thickness mm (in.)            |
|-----------|-------------------------------|
| 0         | 2.40 - 2.45 (0.0945 - 0.0965) |
| 1         | 2.45 - 2.50 (0.0965 - 0.0984) |
| 2         | 2.50 - 2.55 (0.0984 - 0.1004) |
| 3         | 2.55 - 2.60 (0.1004 - 0.1024) |
| 4         | 2.60 - 2.65 (0.1024 - 0.1043) |
| 5         | 2.65 - 2.70 (0.1043 - 0.1063) |

Measure the second and third gear thrust clearances,

Second gear Limit Standard

T

++

0.35 mm (0.014 in.) 0.18 - 0.33 mm (0.007 - 0.013 in.)

Third gear Limit 0.35 mm (0.014 in.) Standard 0.13 - 0.28 mm (0.005 - 0.011 in.)

Fig. 3-62



Lock the nut when the punch mark on the shift arm pivot is positioned straight up.

++

1.

case.

Fig. 3-64



Fig. 3-65



2. Mount SST[09314-36010].

Install The Output Shaft Assembly

Insert the output shaft assembly into the

- 3. Using SST[09309-36020], drive in the bearing.
- 4. Remove SST [09314-36010].

Fug. 3-66



# \*+

# Install The Input Shaft, Bearing, And Ring.

1. Apply grease to the input shaft and assemble in the 17 bearing rollers.





50.77

A .....

# INSTALLATION

Installation Of Transfer To Transmission Install in the numbered order shown below.



 

 Tightening torque
 5 - 8 kg-m (36 - 58 ft-lb)

 - Caution Make sure to position the gears in correct direction.

 Fig. 3-76
 Use SST[09316-60010].

Fig. 3-77



Using SST [09330-00020] to keep the transfer output shaft from turning, tighten the nut. Tightening torque 11 - 14 kg-m (80 - 101 ft-lb)

Stake the nut with a punch to prevent loosening.

Fig. 3-78



Check the shifting conditions of the transfer shift lever and the turning condition of the output shaft.

## Installation Of Transmission To Vehicle

1. Make the installation in the numbered order shown in the figures.





# 3-34 TRANSMISSION & TRANSFER - 4-Speed Transmission (H41, H42)





3-35





Install in the numbered order shown at left. For parking brake adjustment, refer to section on brakes.

# 3-SPEED TRANSMISSION (J30)

#### REMOVAL

Refer to the section on 4-Speed Transmission.

#### DISASSEMBLY

Disassemble in the numbered order shown in the following figures.



## 3-38 TRANSMISSION & TRANSFER – 3-Speed Transmission (J30)



Use SST[09910-00013].

## Fig. 3-88



(= =)

**(--)** 

Using  $\ensuremath{\mathsf{SST}}\xspace[09311-60010]\xspace$  , drive out the shaft toward the rear,

Fig. 3-89



Fig. 3-90



Using a brass bar, hammer the output shaft until the bearing is loosened from the case.

Fig. 3-91



Use SST[09950-20010] and [09956-00010].

**\*\*** 





Fig. 3-93

←→ Use SST[09905-00010].

Using a drift pin, drive out the shaft.





#### INSPECTION

After washing all disassembled parts, inspect them as instructed below. Replace all parts that are found defective.

Fig. 3-95



# Jæ

Transmission Case And Front Bearing Retainer Inspect for damage and wear.









Fig. 3-102



# 

#### Clutch Hub Sleeve, Clutch Hub, Shifting Keys, Shifting Key Springs

- 1. Disassemble the clutch hub and sleeve.
- 2. Inspect the splines of hub and hub sleeve for damage and wear.
- 3. Inspect the humped part at center of key for damage and wear.
- 4. Inspect the key springs for weakening and damage.

 Assemble the hub sleeve (2), three shifting keys (3) and two key springs (4) to the clutch hub (1).

– Note –

1. Hub and hub sleeve are parts having directionality.

- 2. Install the key springs positioned so that their end gaps will not be in line.
- 3. Check the hub and hub sleeve to see that they slide smoothly together.

#### Shift Forks

T

Check the clearance between the hub sleeve groove and the shift fork.

Second-third and first-reverse clearances Limit 0.8 mm (0.032 in.)

Fig. 3-103

in T



# 1.

#### Input Shaft

Inspect the gear teeth, splines, coned surfaces, and bearings for wear and damage.



**←**⇒ **→**← 2. Input shaft bearing replacement.

- a. Remove the snap ring, using SST[09905 -00010]
- b. Remove the bearing, using a press.
- c. Install the new bearing, using SST[09316 -60010] and a press.

Fig. 3-105



Fig. 3-106



Fig. 3-107



d. Select a snap ring of the thickness that will allow minimum axial play, and install it on the shaft.

Snap Ring Sizes

| Part No.    | Thickness mm (in.)        |
|-------------|---------------------------|
| 90520-33010 | 2.43-2.57 (0.0957-0.1012) |
| 90520-33011 | 2.30-2.42 (0.0906-0.0953) |

## **Countergear And Countershaft**

- 1. Inspect the countergear teeth for damage and wear.
- 2. Inspect the bearings and countershaft for damage and wear.
- 3. Inspect the thrust washers for damage and wear.



ໄຈ

# Reverse Idler Gear, Bearings, And Shaft

Inspect the gear, bearings, and shaft for wear and damage.

# 3-44 TRANSMISSION & TRANSFER – 3-Speed Transmission (J30)

#### ASSEMBLY

Assemble in the numbered order shown in the following figures.









Use SST[09905-00010].

Fig. 3-111



|   | 7/1 | 1 | L |
|---|-----|---|---|
| 3 | Ð   |   | L |
| 2 | 2   |   | L |
|   |     |   | 1 |

\*

\*

4

Measure the second gear thrust clearance. Limit 0.4 mm (0.016 in.) Standard 0.08 – 0.23 mm (0.0032 – 0.0091 in.)

Snap Ring Thickness

| Part No.    | mm (in.)                  |
|-------------|---------------------------|
| 90520-33132 | 2.35-2.40 (0.0925-0.0945) |
| 90520-33172 | 2.25-2.30 (0.0886-0.0906) |

Fig. 3-112



Install as illustrated at left.

- Note -

Coat multipurpose grease on the bearing, washer, and spacer before installing.

Fig. 3-113



Assemble the countergear assembly as illustrated at left, and install in the case, using SST[09311-60010].

- Note -

Coat multipurpose grease on the bearing, washer, and spacer before installing.





Fig. 3-119



While holding down the locking ball, drive in the shaft, and then lock the shaft with straight pin.

Install the retainer with its oil hole positioned downward.

++

# INSTALLATION

Install the transfer to the transmission in the numbered order shown below.




Fig. 3-124



Bearing

Using SST[09330-00020] to keep the transfer output shaft from turning, tighten the nut. Specified torque 14 - 15 kg-m (101 - 109 ft-lb) Secure the nut with lock washer.

- Note -Perform the work at front drive condition.

## Install The Transmission With Transfer To The Vehicle.

Refer to the section on 4-Speed Transmission.

Fill in the coolant, and the transmission and transfer oils. Transmission oil capacity 1.7 liter (1.8 US.qt.,1.5 Imp.qt.) Transfer oil capacity 1.7 liter (1.8 US.qt.,1.5 Imp.qt.) Type SAE 90,API GL-4

## TRANSFER

## REMOVAL

Refer to the section on 4-Speed Transmission,

## DISASSEMBLY

Disassemble in the order numbered in the following illustrations.

## Fig. 3-126







3-53

## 3-54 TRANSMISSION & TRANSFER - Transfer

Fig. 3-128







## Fig. 3-137



Remove the stopper, and take out the spring, spacer, and bolt.

## INSPECTION

Wash the disassembled parts and inspect them as instructed below. Replace all parts found defective.

Fig. 3-138



Fig. 3-139



# Jæ

0

#### **Transfer Case And Cover**

Inspect the case and cover for cracks and damage. Inspect the oil seals and bushings for wear and damage.

Fig. 3-140



### **Output Shaft**

Inspect the parts indicated by arrows for wear and damage.

3–57



 Start root,

 Start root,

++

ໄຈ

Fig. 3-147

Fig. 3-145

SS

Fig. 3-146



Fig. 3-148



## **Extension Housing**

**Idler Gear Assembly** 

Inspect for wear and damage.

1. Inspect the shaft, bearing, and oil seal for wear and damage.



3-59

- b. Remove the snap ring.
- c. Using a press, remove the bearing together with the shaft.

Fig. 3-150



Fig. 3-151



d. Using SST[09316-60010], replace the bearing.

- e. Using SST[09316-60010], install the bearing together with the shaft.
- f. Install the snap ring.
- g. Using SST[09316-60010], install the oil seal.

Fig. 3-152



100

#### Diaphragm (Magnet type only)

Inspect the diaphragm for cracks and damage.

## ASSEMBLY

Assemble the parts in the order numbered in the following illustrations.

#### Fig. 3-153











#### Fig. 3-156



Fig. 3-157



Fig. 3-158



\*\* Install the idler gear assembly and shaft as illustrated.

Thrust clearance 3 Ð

## Standard 0.1 - 0.3 mm (0.004 - 0.012 in.) Spacer Thickness

| Part No.    | Thickness mm (in.)    |
|-------------|-----------------------|
| 36261-60010 | 1.2-1.3 (0.047-0.051) |
| 36262-60010 | 1.3-1.4 (0.051-0.055) |
| 36263-60010 | 1.4—1.5 (0.055—0.059) |

Use SST[09316-60010].

inside the case. - Note -

direction.

- Note -Make sure that the gear is positioned in correct direction.



Fig. 3-159



Install the clutch sleeve to the output shaft. Install the output shaft assembly to the case after inserting it through the low speed gear, washer, and bearing.





Using SST[09316-60010], fit the bearing to the output shaft.

Fig. 3-161



SST

++

Drive in the shaft from the rear side of case. – Note –

Position the fork in the direction shown in the figure.

Position the lever tip to align with the shift fork

groove, and install the cover.

Fig. 3-162



++

Fig. 3-163



Install the clutch sleeve to the output shaft.

Note –
 Make sure that the clutch sleeve is positioned in the correct direction.



Fig. 3-168



Fig. 3-169



Fig. 3-170



Disengage the front drive. Using spring scale, measure

Using spring scale, measure the output shaft bearing preload. Standard preloads

 $\begin{array}{l} \text{Bearing replaced} \quad 1.2 - 4.1 \text{ kg} \\ (2.6 - 9.0 \text{ lbs.}) \\ \text{Old bearing reused More than} \\ 0.47 \text{ kg} \ (1.04 \text{ lbs.}) \end{array}$ 

If the preload is up to the standard value, stake the nut to lock it in place: If not up to the standard value, adjust by selecting proper thickness shims.

Adjust Shim Thickness

| Part No.    | Thickness mm (in.) |
|-------------|--------------------|
| 90564-64017 | 0.10 (0.0039)      |
| 90564-64023 | 0.15 (0.0059)      |
| 90564-64024 | 0.20 (0.0079)      |
| 90564-64025 | 0.25 (0.0098)      |

Insert the fork properly into the sleeve.

## INSTALLATION

Refer to the instructions in the 4-Speed and 3-Speed Transmission Sections.

## PROPELLER SHAFT

1

4

page

## PROPELLER SHAFT

## DISASSEMBLY

Disassemble the parts in the order numbered below.

## Fig.4-1







Place mating marks on the flange yokes, spiders, sliding yoke and propeller shaft.

## PROPELLER SHAFT – Propeller Shaft 4–3



### ASSEMBLY

Assemble the parts in the order numbered below.

## Fig. 4-7



The spider grease nipple is located at the sliding yoke.



Fit in the bearing rollers by coating them with grease.

Fig. 4-10



Fig. 4-11



Make the assembly with a snap ring selected to provide the spider with a play not exceeding 0.05

Press in the bearing.

++

4

mm (0.002 in.) Snap Ring Thickness

| Part No.    | Thickness mm (in.)        |
|-------------|---------------------------|
| 90520-29286 | 1.48-1.53 (0.0583-0.0602) |
| 90520-29287 | 1.53-1.58 (0.0602-0.0622) |
| 90520-29288 | 1.58–1.63 (0.0622–0.0642) |

Fig. 4-12



Assemble the sliding yoke, bearing, and propeller shaft with their mating marks aligned. – **Note** –

Have the yoke and grease nipple positioned as shown in figure.

# REAR AXLE

page

| CUTAWAY VIEW                                |
|---|
| REAR AXLE SHAFT(SEMI-FLOATING TYPE) · 5- 3  |
| REAR AXLE SHAFT(FULL FLOATING TYPE) 5-8     |
| REAR AXLE HUB(FULL FLOATING TYPE) ···· 5-11 |
| DIFFERENTIAL                                |

5

## CUTAWAY VIEW

## Fig. 5-1



## REAR AXLE SHAFT (SEMI-FLOATING TYPE)

#### REMOVAL

Drain out the oil and remove the parts in the order numbered below.

Fig. 5-2



Fig. 5-3



←→ Remove the pinion shaft pin.

Fig. 5-4



Draw out the pinion shaft and spacer.

Fig. 5-5



**←**→

++

Push the axle shaft to the center of vehicle and remove the axle shaft lock.



## INSTALLATION

Install the parts in the order numbered in figure.





Fig. 5-12



Fig. 5-13



Fig. 5-14



Measure the differential gear backlash.

E

E

1. Hold the side gear steady and measure the backlash of the pinion.

Standard value 0.02 - 0.20 mm (0.0008 - 0.0079 in.)

2. If outside the standard value range, correct by selecting proper size side gear thrust washers.

Thrust Washer Thickness

| Part No.    | Thickness mm (in.) |
|-------------|--------------------|
| 41361-35010 | 1.6 (0.063)        |
| 41362-35010 | 1.75 (0.069)       |
| 41363-35010 | 1.90 (0.075)       |
| 41364-35010 | 2.05 (0.081)       |

Rear axle shaft end thrust clearance.

Select pinion shaft spacer of the thickness that will set the thrust clearance to the standard value. Standard value 0.06 - 0.46 mm

(0.0024 – 0.0181 in.)

Spacer Thickness

| Part No.  | Thickness mm (in.)   |  |
|---|--|--|
| 41344-35010<br>41345-35010<br>41346-35010<br>41347-35010<br>41348-35010 | 29.8 (1.173)<br>30.2 (1.189)<br>30.6 (1.204)<br>29.0 (1.142)<br>29.4 (1.157) |  |

Fig. 5-15



After installing the axle shaft, fill in hypoid gear oil SAE90, API GL-5.

| Standard | capacity |
|----------|----------|
| orundund | oupdoity |

| FJ40 & BJ40     | 2.4 liter                 |
|-----------------|---------------------------|
|                 | (2.6 US.qt., 2.1 Imp.qt.) |
| FJ43 & BJ43     | 2.7 liter                 |
|                 | (2.9 US.qt., 2.4 Imp.qt.) |
| FJ45, HJ45 & FJ | 55                        |
|                 | 2.9 liter                 |
|                 | 12 1 LIC at 2 G Imp at )  |

(3.1 US.qt., 2.6 Imp.qt.)

## REAR AXLE SHAFT(FULL FLOATING TYPE)

## REMOVAL

Remove the parts in the order shown below.

Fig. 5-16





### INSTALLATION

Install the parts in the order shown in the figure below. Fig. 5-20



## REAR AXLE HUB (FULL FLOATING TYPE)

## REMOVAL

Remove the parts in the order shown below.

Fig. 5-22







Bearing replacement
 Remove the bearing outer race with a drift.

Fig. 5-28



(2) Install with SST[09608-35012].

Fig. 5-29



Pack MP grease into the hub and bearing. Apply MP grease to the oil seal lip.
#### INSTALLATION

Install the parts in the order shown below. Fig. 5-30





Fig. 5-31

## DIFFERENTIAL

#### REMOVAL

After draining out the oil, remove the parts in the order numbered below.

#### Fig. 5-35



## DISASSEMBLY

Disassemble the parts in the order numbered below.

#### Fig. 5-37



5-17



Before starting disassembly, measure the runout of the ring gear back face. Limit 0.1 mm (0.004 in.)

Fig. 5-39



Fig. 5-40





Place mating marks on the bearing caps.

Fig. 5-41



Loosen the staked parts of the nut, and using  $\ensuremath{\mathsf{SST}}\left[09330\text{-}00020\right]$  , remove the nut.

— Note —

(m = )

Hold the gear part of the drive pinion with hand, and remove the flange by tapping the pinion gear with a plastic hammer.



#### Fig. 5-45



Fig. 5-46



Fig. 5-47



a. Remove with SST [09950-20010].

Differential Case, Side Bearings, And

wear, and burning.

Inspect the case for cracks.

4. Side bearing replacement.

1. Inspect the ring gear teeth for damage,

2. Inspect the side bearings for damage and

Fig. 5-48



b. Install with SST[09505-20010].

- Caution -Make sure to reinstall the shim to the back side of outer race at gear side that was removed at disassembly.

b. Install with SST[09608-35012].

4

0

(a a)

**Ring Gear** 

З.

wear.









90560-30185

90560-30186

90560-30187

2.78 (0.1094)

2.81 (0.1106)

2.84 (0.1118)

90560-30191

90560-30192

90560-30199

2.93 (0.1154)

2.96 (0.1165)

2.99 (0.1177)

#### ASSEMBLY AND ADJUSTMENT

Assemble the parts in the order numbered below. - Note -

Coat hypoid gear oil on the bearings, thrust washers, and similar parts before assembling them.

#### Fig. 5-59







Assemble the bearing cups to the side bearings and install the differential case to the carrier. - Caution -

- 1. Use care not to intermix the left and right bearing cups.
- 2. Make sure that backlash has been provided between the ring gear and drive pinion.

Assemble the adjusting nuts to their respec-

tive carriers with the threads fitted on

Fig. 5-61



Fig. 5-62



Fig. 5-63



- Screw in the two bearing cap bolts two or three turns and press down the bearing cap with hand.
- Caution –

1.

properly.

- 1. If the bearing cap does not fit tightly on the carrier, the adjusting nut threads are not fitting properly so that operations 1 and 2 above must be repeated.
- 2. Make sure that the bearing cap mating mark is aligned with that on the carrier.

Side bearing preload adjustment

- 1. Tighten the bearing cap bolts until the spring washers are slightly compressed.
- 2. Using SST[09504-00010] tighten both the left and right adjusting nuts to seat the bearing cups in the carrier.

5-25



Fig. 5-65



Fig. 5-66



Fig. 5-67



- 3. Mount a dial gauge to the carrier with the plunger set on the rear face of ring gear.
- 4. Tighten the adjusting nut until side play is removed, and from this zero-play position, tighten the adjusting nut further one to two notches.
- 5. Tighten the bearing caps at the specified torque.

Tightening torque 9.0 - 11 kg-m (65.1 - 79.6 ft-lb)

Measure the overall preload. Specified preload (starting) (For both new and old bearing) 4 - 6 kg-cm (3.5 - 5.2 in-lb) + Drive pinion preload

Backlash adjustment

E

6.

3.

- 1. Loosen the bolts installing the left and right bearing caps until the spring washers are loosely compressed.
- 2. Adjust the backlash to the specified value by using SST[09504-00010] and turning the left and right adjusting nuts by equal amounts (such as loosening the left side one notch and tightening the right side one notch).

Specified backlash 0.15 - 0.20 mm (0.0059 - 0.0079 in.)

Tighten the bearing cap bolts at the specified torque.

Tightening torque 9.0 - 11 kg-m (65.1 - 79.6 ft-lb)



#### Fig. 5-70



Fig. 5-71





face positioned toward the gear.

Differential Gear Backlash Measurement1. Hold the pinion gear steady with hand, and measure the side gear backlash.

Standard backlash 0.02 - 0.20 mm (0.0008 - 0.0079 in.)

- If outside the specified limit, correct by selecting proper thickness side gear thrust washers.
- Note –

All efforts should be taken to use same thickness thrust washers at the left and right sides.

Thrust Washer Thickness

| Part No.    | Thickness mm (in.) |
|-------------|--------------------|
| 41361-35010 | 1.6 (0.063)        |
| 41362-35010 | 1.75 (0.069)       |
| 41363-35010 | 1.90 (0.075)       |
| 41364-35010 | 2.05 (0.081)       |

#### INSTALLATION

Install the parts in the order numbered below.

#### Fig. 5-72



SEE REAR AXLE SHAFT SECTION Install the axle shafts. - Note -

Measurement of differential gear backlash shall be excluded.

# FRONT AXLE

#### page

| CUTAWAY VIEW                    | 6-  | 2  |
|---------------------------------|-----|----|
| STEERING KNUCKLE AND AXLE SHAFT | 6-  | З  |
| DIFFERENTIAL                    | 6-1 | 19 |
| FREE WHEEL HUB                  | 6-2 | 20 |

6

## CUTAWAY VIEW



## STEERING KNUCKLE AND SHAFT

REMOVAL

Remove the parts in the order numbered below.







Fig. 6-7



If the spindle does not come off easily, tap it off with a drift and hammer as shown in the photo.

Fig. 6-8





**++** 

Position the flat part of the outer shaft in vertical direction, and pull out the drive shaft.

Fig. 6-9



Remove the dowel by hammering in a screwdriver into the slotted part of the dowel.

Fig. 6-10



Use SST[09611-20014] or SST[09628-62010].

6-5

#### Fig. 6-11



Use SST[09606-60010] to remove the knuckle and bearing cap.

Fig. 6-12





Xeep the removed adjusting shims and bearings properly marked so as to enable reassembling them back to former position.

**++** 

#### INSPECTION

Wash the removed parts and inspect them on the following points. Replace any part found defective.

.

Fig. 6-13



#### Knuckle Spindle

1. Inspect the parts indicated by arrows for wear and damage.









#### ADJUSTMENT

Whenever the axle housing or the steering knuckle is replaced, the front drive shaft alignment and knuckle bearing preload are adjusted with SST[09634-60012].

#### Fig. 6-30



Fig. 6-31



1. Mount the SST[09634-60012] on the housing.

- Note -

Have the knuckle bearings coated lightly with Molybdenum disulphide lithium base grease.

Fig. 6-32



2. Tighten the nut (F) until the spring scale indicates about 2.0 - 2.5 kg (4.4 - 5.5 lb.)

#### Fig. 6-33



Fig. 6-34



Fig. 6-35



Fig. 6-36



3. Measure the distance "A".

M

4. Measure the distance "B".

5. The difference between "A" and "B" is the total adjusting shim thickness that is required to maintain the correct bearing preload.

- 6. Apply a light coat of red lead on the center part of rod (D)
- Press the adapters (A) and (B) against the housing, press the plug (C) against the rod (D), and turn the lever (G) so as to have a line scribed on the rod (D).

| Fig. 6-37                |        | Bolt on the knuckle spindle to the knuckle.<br>Note –<br>stall the bolt over two washers.   |
|--------------------------|--------|---|
| Fig. 6-38                | و<br>ب | Dismount the SST[09634-60012] from the  |
|                          |        | <ul> <li>Caution –</li> <li>Use care not to erase the scribed line when dismounting and remounting the SST.</li> <li>Make sure that the rod (D) is in the same vertical direction that it was when mounted on the housing.</li> </ul> |
| Fig. 6-39                | 10     | Ture the red (D) and earlies another list   |
|                          | 11     | <ul> <li>Turn the rod (D) and scribe another line<br/>on it.</li> <li>Measure the distance "D" between the<br/>two scribed lines.</li> </ul>  |
| Fig. 6-40                | 10     | ·   |
| LOWER SHIM THICKNESS "E" | 12     | bearing shim "E" will be the distance "D"<br>less 3 mm (0.12 in.)   |
| "E"="D"-3mm              |        |   |
|                          |        |   |
|                          |        |   |
|                          |        |   |

#### Fig. 6-41

UPPER SHIM THICKNESS "F"

"F"="C"-"E"

Adjusting Shim Sizes

| Part No.    | Thickness mm (in) |  |
|-------------|-------------------|--|
| 43233-60010 | 0.2 (0.008)       |  |
| 43234-60010 | 0.5 (0.020)       |  |
| 43233-60020 | 1.0 (0.04)        |  |

 The thickness of the steering knuckle upper bearing shim "F" will be difference between the total adjusting shim thickness "C" and the shim thickness "E".

- Note -

Compare "E" and "F" with the thicknesses of the shims removed at disassembly. If there should be considerable difference, remeasure "E" and "F".

#### INSTALLATION

Install the parts in the order numbered below.







| Fig. 6-47 | <ul> <li>1. Measure the knuckle bearing preload.<br/>Specified pull 1.8 - 2.3 kg<br/>(3.9 - 5.0 lb)</li> <li>2. Install the tie rod end to the knuckle arm.<br/>- Caution -</li> <li>If the specified pull is not indicated, correct by varying the number of upper and lower adjusting shims by equal amounts.</li> </ul> |
|-----------|--|
| Fig. 6-48 | <ul> <li>Position the flat part of the outer shaft in vertical direction and install the drive shaft assembly.</li> <li>Caution –</li> <li>1. Use care not to damage the oil seal lip.</li> <li>2. Pack Molybdenum disulphide lithium base grease into the knuckle to about three-fourth of the knuckle volume.</li> </ul> |
| Fig. 6-49 | Install the nuts and lock them with the lock wire.<br>Tightening torque 1.5 – 2.2 kg-m<br>(10.9 – 16.0 ft-lb)  |
| Fig. 6-50 | Pack multipurpose grease into the hub and<br>bearing.<br>Apply multipurpose grease to the oil seal lip.  |
|           |  |



## DIFFERENTIAL

( Martin C

#### REMOVAL

Remove the parts in the order numbered below.

#### Fig. 6-54



#### Fig. 6-55



Remove the axle shafts.

#### DISASSEMBLY AND ASSEMBLY

Refer to the disassembly and assembly procedures for the differential in the Rear Axle and Rear Suspension Section.

#### INSTALLATION

Perform the removal in reverse order.

#### Fig. 6-56



After installing the axle shaft fill in hypoid gear oil SAE90, API GL-5. Standard capacity

FJ, BJ & HJ series 2.5 liter (2.6 US.qts., 2.2 Imp.qts.)

#### FREE WHEEL HUB

#### REMOVAL

Remove the parts in the order shown below.

#### Fig. 6-57



Fig. 6-58


Remove the cone washer.

Fig. 6-60



#### DISASSEMBLY

Disassemble the parts in the order shown below.

Fig. 6-61





Remove the snap ring and free wheel hub ring.

Fig. 6-63



Use SST[09905-00010].

**\* \*** 

Fig. 6-64



Remove the snap ring, cover and handle.

#### Fig. 6-65



Fig. 6-66



Fig. 6-67



#### INSPECTION

Wash the disassembled parts and inspect them on the following points.

#### Inner And Free Wheel Hub Ring

- Inspect for wear or damage.
  Oil clearance limit (A B)
  - 0.3 mm (0.012 in.)

#### **Body And Clutch**

 Inspect for wear, damage or rust.
 Verify that the clutch moves smoothly in the body.



#### Cover, Handle And "O" Ring

- 1. Inspect for wear or damage. 2. Rotate the control handle of the hub back
  - and forth to make sure that it moves smoothly and freely.

#### ASSEMBLY

Assemble the parts in the order shown below.

#### Fig. 6-68



Fig. 6-69



Multipurpose Grease

Apply MP grease on the arrow mark portion, before assembling.

Before assembly, apply MP grease as indicated on the photo.





#### INSTALLATION

Install the parts in the order shown below.

## Fig. 6-78



G





Tighten six nuts to the specified torque. **Tightening torque** (18.1 – 25.3 ft-lb)

Fig. 6-80



Use SST[09905-00010].

- Note -Gripping a bolt, pull the axle shaft out to install the snap ring.



# STEERING

#### page

| STEERING | WHEEL  | & MAIN   | SHAFT | •••••                                   | 7-           | 2  |
|----------|--------|----------|-------|---|--------------|----|
| INTERMED | ATE SH |          | ••••• | •••••                                   | 7-           | 7  |
| STEERING | GEAR H | OUSING   |       | • | <b>7</b> - 1 | 1  |
| STEERING | LINKAG | E        |       |   |              |    |
| & FRONT  | WHEEL  | . ALIGNN |       |   | 7-2          | 24 |

## STEERING WHEEL AND MAIN SHAFT

-

#### REMOVAL

Remove the parts in the order numbered below.





Place mating marks on the gear box, couplings, and main shaft.

Fig. 7-3



 $\overline{\mathbb{N}}$ 

Place mating marks on the yoke and main shaft.

#### DISASSEMBLY

Disassemble the parts in the order numbered below.





#### ASSEMBLY

Perform the disassembly in reverse order. - Note -

- 1. Pack grease into the upper bearing.
- 2. Align the mating marks when installing the steering wheel.

INSTALLATION

Perform the removal in reverse order. - Note -Align the mating marks when installing the steering column assy.

## INTERMEDIATE SHAFT

#### DISASSEMBLY

Disassemble the parts in the order numbered below.

Fig. 7-9



Fig. 7-10



Remove the bearing cup by lightly tapping the yoke with a hammer. - Note -

Hold downward the bearing and spider at the other end while tapping the yoke.





#### INSPECTION

Inspect the spider and bearing for damage and wear.



Inspect the splines for wear and damage.

#### ASSEMBLY

Assemble the parts in the order numbered below.





Fig. 7-16



Select snap rings of the thickness that will provide minimum thrust clearance in the joint spider but will still allow the joint spider to operate smoothly.

| Snap | Ring | Thickness |
|------|------|-----------|
|      |      |           |

| Part No.                                  | Thickness mm (in.)                              |   |
|---|---|---|
| 90521-22011<br>90521-22012<br>90521-22013 | 1.20 (0.0424)<br>1.25 (0.0492)<br>1.30 (0.0512) | _ |



Make the assembly so that the steering yokes will be positioned in the same direction.

## STEERING GEAR HOUSING

#### REMOVAL

Remove the parts in the order numbered below.



SEE STEERING WHEEL AND MAIN SHAFT SECTION

Fig. 7-19



arm.

←→ Using SST[09610-55011], remove the pitman

Remove the steering wheel and main shaft.

#### DISASSEMBLY

Disassemble the parts in the order numbered below.











**(= =)** 

Fig. 7-35



- Replacement of gear housing bushings.
  a. Remove the oil seal.
  - b. Using SST[09307-12010], press out the two bushings at the same time in the same direction.

7-17





Fig. 7-37



Fig. 7-38



c. Using SST[09307-12010], press in the bushings from each end of the gear box.

d. Hone the bushings with a pin hole grinder or similar means until standard oil clearance is obtained between the bushings and the sector shaft.

Standard clearance 0.009 - 0.060 mm (0.0004 - 0.0024 in.)

- e. Install the oil seal.
- Measure the sector shaft thrust clearance, and select a thrust washer that will provide minimum clearance between the sector shaft and the adjusting screw.
   Clearance limit 0.1 mm (0.004 in.)

Thrust Washer Thickness

| Part No.    | Mark | Thickness mm (in.) |
|-------------|------|--------------------|
| 45352-36010 | 1    | 2.00 (0.0787)      |
| 45353-36010 | 2    | 2.05 (0.0807)      |
| 45354-36010 | 3    | 2.10 (0.0827)      |
| 45355-36010 | 4    | 2.15 (0.0846)      |
| 45356-36010 | 5    | 2.20 (0.0866)      |
|             |      |                    |

#### ASSEMBLY

Assemble the parts in the order numbered below.







Shim Thickness

| Part No.    | Mark     | Thickness mm (in.) |
|-------------|----------|--------------------|
| 45323-36010 | 1        | 0.05 (0.0020)      |
| 45323-36020 | 2        | 0.07 (0.0028)      |
| 45323-36030 | 3        | 0.08 (0.0032)      |
| 45323-36040 | 4        | 0.10 (0.0039)      |
| 45323-36050 | 5        | 0.12 (0.0047)      |
| 45323-36060 | 6        | 0.5 (0.020)        |
| 45323-36070 | <b>7</b> | 0.06 (0.0024)      |
| 45323-36080 | 8        | 0.09 (0.0035)      |

Fig. 7-42



Install the cover over the same amount of shims removed at disassembly, and tighten the cover bolts at specified torque.

3 – 4.5 kg-m (21.7 - 32.5 ft-lb)

- Note -

Tightening torque

(G

- 1. Have the worm bearing lubricated with gear oil.
- 2. While tightening the cover bolts, keep checking the worm to see that it will turn properly.

Measure the worm bearing preload. Specified preload  $4.0 - 6.0 \ \text{kg}$ (8.8 - 13.2 lb)

- Note -

4

Read the scale just when the worm starts to turn. If the preload is not within the specified limits, correct by selecting proper thickness shim.

Position the worm ball nut at the center and insert the sector shaft.

– Caution – Make sure that the worm ball nut and the sector

are meshing together at the center.



### INSTALLATION

Install the parts in the order numbered below. Fig. 7-47







Fill in gear oil.

Standard capacity 0.6 liter (0.6 US qt, 0.5 Imp.qt.) Type SAE 90 API GL4

## STEERING LINKAGE & FRONT WHEEL ALIGNMENT

## REMOVAL AND DISASSEMBLY Fig. 7-52





Di nu

Disassemble the parts in the order shown by numbers.

7-25

Fig. 7-54



Fig. 7-55



Use SST[09628-62010] or SST[09611-20014].



**\*\*** 

Disassemble the parts in the order shown by numbers.

To remove the arm (2), use  $\ensuremath{\mathsf{SST}}\xspace{0.05ex}$  [09628-62010].












### Fig. 7-65



#### Toe-in

#### Side slip

Check the side slip with a side slip tester after adjusting the toe-in and checking the camber, caster, and king pin inclination.

The side slip should be less than 3 mm (0.12 in.) per 1 meter (3.3 ft.) running distance. If the side slip exceeds this amount, readjust the front alignment.

– Note –

- 1. Before starting to adjust the front wheel alignment, inspect on the following points and correct any faults found.
  - a. Tire pressure and abnormal tire wear.
  - b. Wheel run-out and unbalance.
  - c. Steering knuckle bearing wear (looseness)
  - d. Tie-rod end wear (looseness)
  - e. Front wheel bearing looseness.

Adjustment of front wheel alignment must never be attempted until all defects have been corrected.

2. The camber and caster cannot be adjusted.

# BRAKE

|  | page         |
|--|--------------|
| ADJUSTMENT                               | 8- 2         |
| SINGLE MASTER CYLINDER                   | 8-5          |
| TANDEM MASTER CYLINDER                   | 8-7          |
| TANDEM MASTER CYLINDER(FOR USA & CANADA) | 8-11         |
| BRAKE BOOSTER                            | 8-16         |
| BRAKE BOOSTER(TANDEM TYPE)               | 8-25         |
| VACUUM PUMP                              | 8-37         |
| FRONT BRAKE(DRUM TYPE)                   | 8- <b>43</b> |
| FRONT BRAKE(DISC TYPE)                   | 8-49         |
| REAR BRAKE ······                        | 8-58         |
| PARKING BRAKE                            | 8-64         |

8







## ADJUSTMENT

**BRAKE PEDAL** 

## Pedal Height

1. Vehicles with brake booster

- a. Sufficiently loosen the stop light switch (1).
- Adjust the pedal height by turning the push rod (2).
- c. Return the stop light switch until its body lightly contacts the pedal stopper.
- Vehicles without brake booster
  a. Loosen the push rod (2)
  - a. Loosen the push rod (2).b. Adjust the pedal height by turning the stop light switch (1).
  - c. Adjust the push rod (2) while referring to the methods described in Pedal Play Adjustment.

Standard Pedal Heights

|                     | w/brake booster<br>mm (in.) | w/o brake booster<br>mm (in.) |
|---------------------|-----------------------------|-------------------------------|
| FJ, HJ, BJ40 Series | 215 (8.46)                  | 198 (7.80)                    |
| FJ55 Series         | 185 (7.28)                  | 172 (6.77)                    |

#### **Pedal Play**

- 1. Vehicles with brake booster
  - Stop the engine and depress the brake pedal several times until there is no more vacuum left in the booster.
  - b. Press down the pedal with fingers until initial resistance is felt. The amount of play sensed at this time should be within the specified range. Pedal play 3-6 mm (0.12-0.23 in.)

– Note –

- 1. If the pedal play is not within the specified range, adjust the pedal height by the method described in Pedal Height so as to provide the proper amount of pedal play.
- 2. The pedal play is not the amount of stroke up to the time the booster piston starts to move.
- 2. Vehicle without brake booster
  - a. Adjust the pedal play by turning the push rod (2) and adjusting the clearance at push rod tip.

Pedal play 3-6 mm (0.12-0.23 in.)

8-2



#### Fig. 8-4



#### SHOE CLEARANCE

#### Pedal Reserve Travel

Pedal reserve travel 80 mm (3.15) minimum --- FJ, HJ, BJ40 Series

70 mm (2.76) minimum

#### --- FJ55 Series

If the reverse travel less than the specified value, adjust the shoe clearance.

#### Shoe Clearance Adjustment

- 1. Remove the plugs from shoe adjusting holes.
- 2. Check the wheel to see that it turns smoothly.
- 3. Insert the SST[09704-10010] through the adjusting hole, and turn the wheel cylinder adjusting nut by moving the tool tip from the wheel center toward the rim so as to expand the shoes.
- 4. Keep on turning the adjusting nut until the shoes are expanded and the adjusting nut cannot be turned further. Then, depress the brake pedal and try to expand the shoes further so as to insure proper contact against the drum.
- 5. Now, turn the adjusting nut in reverse direction, by moving the tool tip from the wheel rim toward the center, and carefully retract the shoes until the wheel can be turned lightly.

A number of notches to be returned is from 4 to 5.

6. Install the plugs in the shoe adjusting holes. – Caution –

Check the brake pedal to make sure that there is sufficient reserve travel.



#### PARKING BRAKE

- 1. Turn the adjuster counterclockwise until the brake shoes are fully expanded.
- 2. Return the adjuster one notch.
- Check the brake drums to see that the brakes are not dragging after pulling the parking brake lever all the way back and then releasing it. If dragging, return the adjuster another notch.

8-4 BRAKE - Adjustment





Adjust the parking brake lever reserve pull by means of the turnbuckle (FJ55) or the cable end nut (FJ, HJ, BJ40).
 Standard 7 – 12 notch

## SINGLE MASTER CYLINDER

DISASSEMBLY

Disassemble the parts in the order numbered below.







**Piston Assembly And Check Valve** Inspect for wear and scores.

Fig. 8-10



### ASSEMBLY

Perform the disassembly in reverse order.

– Note –

Before installing, apply rubber grease to the parts indicated by arrows.

## TANDEM MASTER CYLINDER

## DISASSEMBLY

Remove the parts in the order numbered below.





### ASSEMBLY

Assemble the parts in the order numbered below.

#### Fig. 8-15

.



\*





Front Front Rubber Grease Before assembling, apply rubber grease to the parts indicated by arrows. - Caution -

Assemble the long spring at the front side.

Make sure that the pistons are assembled in correct directions.

Fig. 8-18



Install with the UP mark positioned at the upper side.

++

Fig. 8-19



With the pistons pushed in all the way, install the bolt.

## TANDEM MASTER CYLINDER(FOR USA & CANADA)

#### DISASSEMBLY

Remove the parts in the order shown below.







With the pistons pushed in all the way, remove the bolt.

#### Fig. 8-22







**Piston Assembly** Inspect for wear or scores.

Fig. 8-24





Out Insp

Outlet Check Valve Inspect for damage.

## INSPECTION

Inspect the disassembled parts on the following points, and repair or replace all defective parts found.

#### Master Cylinder Body

Inspect for wear or scores.

#### ASSEMBLY

Assemble the parts in the order shown below.



Fig. 8-26 Assemble the long spring at the front side. Front auu **N** Long Short Fig. 8-27 Before assembling, apply rubber grease to the parts indicated by arrows. Front - Caution -Make sure that the pistons are assembled in correct directions. Rubber Grease Fig. 8-28 Install with the UP mark positioned at the upper ++ side. UP Mark

Fig. 8-29



With the pistons pushed in all the way, install the bolt.

++

### Fig. 8-30



Install the check valve with bakelite positioned on the upper side.

## BRAKE BOOSTER

#### DISASSEMBLY

Disassemble the parts in the order numbered below.







Remove the retainer with a screwdriver.

**+++** 

Fig. 8-33



Using SST[09738-20010] and a press, remove the body connector by turning it counterclockwise.

Fig. 8-34



←→ Remove the snap ring.

Fig. 8-35



Remove the retainer by turning it counterclockwise with SST[09736-30020].





Vacuum Check Valve

Check the operation of valve,

#### 8-20 BRAKE - Brake Booster

#### ASSEMBLY

Assemble the parts in the order numbered below.









Fig. 8-47



Fig. 8-48



\*

Using SST [09738-20010] and a press, install the body connector by turning it clockwise.

Install the plate with its protrusion directed upward.

++

Install the retainer with the lipped part facing outward.

Assemble together the front and rear bodies with

their vertical directions aligned.







2. Turn the SST upside down and set it on the booster. Then adjust the booster push rod length until the rod end is in light contact with the pin head.

## BRAKE BOOSTER(TANDEM TYPE)

#### DISASSEMBLY

Disassemble the parts in the order shown below.















Fig. 8-69



#### Fig. 8-70



Vacuum Check Valve Check the operation of valve.

## Hub, Rod, Reaction Disc And Reaction Disc Hub

Inspect for cracks, damage, wear, bending or corrosion.

## Valve Body

Check the operation of valve.

#### ASSEMBLY

Assemble the parts in the order shown below.











Install the hub, rear diaphragm plate and rear diaphragm.

Fig. 8-77



Install the center plate onto the hub with its large groove positioned to the front side.

Fig. 8-78



Install the rear diaphragm retainer.

Fig. 8-79



Install the front diaphragm retainers as shown.




Tighten the nut, then stake the nut.

Fig. 8-81



Assemble together the front and rear shell cylinders with their vertical directions aligned.



Using SST[09738-22012], [09753-22010], and a press, install the shell cylinder and stud assembly until the rear shell cut is securely against the stopper.

- Note -If the rear shell is too tight and cannot be turned, re-apply oil on the diaphragm edge which contacts with the front and rear shells.

Fig. 8-83



Install the sponges and felts as shown.





Booster Push Rod Length Adjustment

The length of booster push rod is adjusted to provide the specified clearance between the push rod end and the master cylinder piston. Standard Clearance (Without Vacuum)

0.6 – 0.65 mm (0.024 – 0.026 in.)

Fig. 8-85



Fig. 8-86



contacts the piston slightly.

Set the  $\ensuremath{\mathsf{SST}}[09737\text{-}00010]$  on the master

cylinder, and lower the pin until its tip

1.

2. Turn the SST upside down and set it on the booster. Then adjust the booster push rod length until the rod end contacts the pin head slightly.

# VACUUM PUMP

# REMOVAL

Remove the parts in the order numbered below.

### Fig. 8-87



**\*\*** 

Fig. 8-88



Disconnect the oil hoses.

– Caution –

Oil hose is contained in the hoses so avoid spilling it out when removing the hoses.



# DISASSEMBLY

Remove the parts in the order numbered below.













# Drive End Frame

E

++

- Inspect the end frame for damage and wear.
  Inspect the oil seal and bushing for damage
  - Inspect the oil seal and bushing for damage and wear.

Bushing bore wear limit 16.14 mm (0.6354 in.)

.

# **Oil Seal Replacement**

- 1. Remove the oil seal by prying it out with a screwdriver.
- 2. Press in the new oil seal with a press.

# ASSEMBLY

Assemble the parts in the order numbered below.

# Fig. 8-98



++

Fig. 8-99



Drive in the pins until their end are protruding out only about 8 mm. - Note -

Apply engine oil on the "O" ring and light coat of grease on the oil seal before installing.



Install the rotor and blades.

- Note -

÷

- 1. Make sure that the blades are positioned in correct direction.
- 2. Coat engine oil on the blades and rotor before installing.

# INSTALLATION

Install the parts in the order numbered below.





Fig. 8-102



Run the engine at low speed after completing the installation.

Loosen the hollow screw at delivery end of vacuum pump and check if oil is circulating within the pump.

# FRONT BRAKE(DRUM TYPE)

# REMOVAL

Remove the parts in the order numbered below.







Return the wheel cylinder adjusting nut with SST[09704-10010] and then remove the drum.

Remove with SST[09703-30010].

Fig. 8-105



Fig. 8-106



Fig. 8-107





**++** 

Disconnect the brake tube and 3-way fitting from the backing plate.

# INSPECTION Inspect the disa

Inspect the disassembled parts on the following points, and repair or replace all defective parts found.

### **Springs And Pins**

Inspect for damage and deformation.



### INSTALLATION

Install the parts in the order numbered below.



|            | BRAKE – Front Brake (Drum Type) 8–47   |
|------------|--|
| Fig. 8-113 | Apply rubber grease on the piston and cup.<br>• Apply non-melt type grease on the adjusting nut<br>and bolt.   |
| Fig. 8-114 | Install the left hand thread adjusting nut and bolt<br>at the right wheel brake.<br>Install the right hand thread adjusting nut and<br>bolt at the left wheel brake. |
| Fig. 8-115 | Install the wheel cylinders.   |
| Fig. 8-116 | Apply non-melt grease to the place indicated by the arrow.   |
|            |  |



# FRONT BRAKE(DISC TYPE)

# REMOVAL

Remove the parts in the order shown below.



Fig. 8-121



- 1. Place a backing board, such as shown in illustration, into the caliper slot, and insert a pad on one side.
- 2. Blow in compressed air through the tube connection hole.
- 3. Remove alternately.

Fig. 8-122





# — Caution —

Never loosen the caliper bolts attaching the caliper halves.

← → Remove36010].

Remove the brake tube using SST[09751-









(4) Remove the lock nut, lock washer and adjusting nut using SST[09607-60020].

(5) Remove the front axle hub and disc.

(6) Separate the disc from the front axle hub.

Fig. 8-130

Fig. 8-129



(7) Assemble the disc and front axle hub.

Tightening torque 4.0 - 5.5 kg-m (28.9 - 39.8 ft-lb)

(3) Remove the nuts, washers, cone washers and flange.





Fig. 8-133



(8) Install the front axle hub and disc.

- (9) Tighten the adjusting nut to 6 kg-m (43 ft-lb), using SST[09607-60020].
- (10) Rotate the hub back and forth about three times to snug down the bearing.
- (11) Retighten the adjusting nut to 6 kg-m (43 ft-lb), then unscrew it nut 1/8th to 1/5th turn.

(12) Lock the nut by bending inward one of the lock washer teeth.

Fig. 8-134



(13) Tighten the lock nut to the specified torque.

Tightening torque 8 — 10 kg-m

(58 – 72 ft-lb)

(14) Secure the lock nut with the lock washer.





(15) Install the flange, cone washers, washers and nuts. **Tightening torque** 

2.8 – 3.5 kg-m (20.3 – 25.3 ft-lb)

- (16) Install the snap ring using SST[09905-00010].
- (17) Install the front hub grease cup.

# INSTALLATION

Install the parts in the order shown in the figure below.









Install the brake tube with SST[09751-36010].

Ŗ





Install the anti-rattle spring as shown.

# REAR BRAKE

# REMOVAL

Remove the parts in the order numbered below,







Fig. 8-149



Fig. 8-150



# 🖝 Brake Drum

Inspect for wear, damage, and cracks. Drum inner diameter limit FJ45, HJ45 & FJ55 (Fire truck) 297 mm (11.70 in.) Except FJ45, HJ45 & FJ55 (Fire truck) 292 mm (11.50 in.)



m

- Wheel Cylinder
  - . Inspect the cups for damage and deformation.
  - 2. Inspect the boots for damage and cracks.
  - 3. Inspect the cylinder body bore and piston for wear, damage, rust, and corrosion.
  - 4. Inspect the adjusting nut and bolt for damage and deformation.



# **Backing Plate**

Inspect for damage, crack, and deformation.

# INSTALLATION

Install the parts in the order numbered below.



# 8–62 BRAKE – Rear Brake





hooked on to the inner sides of the shoes.

Fig. 8-157



++

Using  $\ensuremath{\mathsf{SST}}\xspace[09703-30010]$  , install the rear side return spring to the outer side.

# PARKING BRAKE

# REMOVAL

Drain out the oil from the transfer case, and remove the parts in the order numbered below.







Jæ

10

### Backing Plate And Parking Brake Cable

- 1. Inspect the backing plate for wear and cracks.
- 2. Inspect the parking brake cable for damage and its sliding condition.

Fig. 8-164



Fgi. 8-165



### Parking Brake Cable Replacement

Adjuster, Springs And Pins.

Inspect for damage and wear.

- 1. At the backing plate, remove and reinstall the "C" washer.
- 2. At the parking brake lever, refer to the procedures described in Transmission Removal and Installation.

# INSTALLATION

Install the parts in the order numbered in the figure below.
Fill oil into the transfer case.

- - SAE 90 (API GL-4) Туре Capacity

1.7 liter (1.8 US qt., 1.5 lmp.qt.)







# FRONT WINCH

# page

| CUTAWAY VIEW   | 9- | 2  |
|----------------|----|----|
| POWER TAKE-OFF | 9- | З  |
| WINCH ·····    | 9- | 10 |

# CUTAWAY VIEW

Fig. 9-1


## POWER TAKE-OFF

#### DISASSEMBLY

Dissassemble the parts in the order numbered below.







Fig. 9-6



Remove the joint flange by lightly tapping its portion of woodruff key groove.



111

111

Fig. 9-7

Fig. 9-8

Fig. 9-9



# լթ

Reverse Idler Gear And Shaft Inspect for wear and damage.

- Note -

For the bushing replacement, use a socket wrench.





**Output Gear, Shaft And Bearings** 1. Inspect for wear and damage.

Fig. 9-12



- 2. Rear bearing replacement.
  - Remove the bearing with a press. a.
  - b. Install the bearing with a press and SST[09325-12010].

#### ASSEMBLY

Assemble the parts in the order numbered below.

#### Fig. 9-13







Position the output gear into the case with the shift fork groove towards the rear.

Fig. 9-15





Install the bearing with a press and SST [09325-12010].

Fig. 9-16





Using SST[09330-00020] to keep the output shaft from turning, tighten the nut. **Tightening torque** 

1.5 - 2.2 kg-m (10.9 - 15.9 ft-lb)

Fig. 9-17



Place the reverse idler gear and the idler gear spacer into the case with the gear hub to the rear side.

The spacer should be installed between the gear hub and the case.

Fig. 9-18



| - |
|---|
|   |

Place the input gear into the case with the larger gear towards the rear, and mesh with the reverse idler gear. Install the spacer.

9-9

,

### WINCH

#### DISASSEMBLY

Dissassemble the parts in the order numbered below.

#### Fig. 9-19







#### ASSEMBLY

Assemble the parts in the order numbered below.

## Fig. 9-27







-----



Fig. 9-30



Apply multipurpose grease on all bushings, shaft and the clutch mechanism when assembling, and pack multipurpose grease into the drum to about three-fourth of the drum volume.

◆ Place the worm into the case with the straight pin hole towards the rear.



3

- Note - Apply liquid sealer onto the gasket surfaces to prevent oil leak.

Fig. 9-31



Rotate the worm, and check the condition for looseness or tightness, and also rock the worm to-and-fro, and check the worm end play. The worm end play should be zero and it should rotate smoothly.

| Adjusting Shim Thickness |                    |  |  |  |
|--------------------------|--------------------|--|--|--|
| Part No.                 | Thickness mm (in.) |  |  |  |
| 38123-60010              | 0.228 (0.009)      |  |  |  |
| 38124-60010              | 0.5 (0.020)        |  |  |  |

If necessary, adjust the worm bearing pre-load by selecting the adjusting shims to obtain the proper condition.

#### Fig. 9-32



Fig. 9-33



**→**← Ir

Install the case cover with its filler hole positioned downward.

Fill the gear case with gear oil. Gear case oil capacity 0.6 liter (US qt. 0.6, Imp.qt. 0.5) Type SAE 90, API GL-4

# FRAME

induction of the second

THATT TO NOT

.

| IMPORTANT DIMENSION OF FRAME |      |
|------------------------------|------|
| FJ40, BJ40 SERIES ······     | 10-2 |
| FJ43, BJ43 SERIES ······     | 10-3 |
| FJ45, HJ45 SERIES ······     | 10-4 |
| FJ55 SERIES                  | 10-5 |

10

#### IMPORTANT DIMENSION OF FRAME

In case the vehicle has crashed or overturned in an accident, the frame could have become twisted. At such time, make the repairs by referring to the important dimensions of the frame.

## FJ40, BJ40 SERIES







FRAME -- Important Dimension of Frame

10-3



10-4

FRAME – Important Dimension of Frame

## FJ55 SERIES

### Fig. 10-4



10-5

# BODY

| FJ55 SERIES       | page |
|-------------------|------|
| HOOD              | 1-2  |
| FRONT DOOR1       | 1-4  |
| REAR DOOR ······1 | 1-8  |
| WINDSHIELD1       | 1-10 |
| TAIL GATE 1       | 1-14 |
| ROOF HEADLINING1  | 1-23 |

## FJ40 SERIES

| НООД11-             | 27 |
|---------------------|----|
| DOOR11-             | 28 |
| BACK DOOR ······11- | 33 |

# 11

## FJ55 SERIES

## HOOD

Fig. 11-1



#### Fig. 11-2



ADJUSTMENT

#### Hood

1. Adjust the hood in front-rear direction by loosening the bolts attaching the hood to the hood hinges.

Fig. 11-3



2. Adjust the hood in lateral direction by loosening the bolts attaching the hood hinges to the body.

#### Fig. 11-4



#### Fig. 11-5



Fig. 11-6



#### Hood Lock

 If the hood lock dowel and hood lock are out of alignment with each other, correct by loosening the mounting bolts.

2. If the hood is loose in vertical direction, or the hood lock does not catch properly correct by adjusting the hood lock hook.



#### Hood Auxiliary Catch Hook

If the catch hook does not latch on properly, correct by loosening the bolts.

## FRONT DOOR

### REMOVAL

#### Door Window Glass and Regulator

Remove in the order of the numbers shown.



|           |    | BODY – Front Door 11–5  |
|-----------|----|---|
| Fig. 11-8 | 1. | Remove the two bolts attaching the glass<br>channel.                        |
| Fig. 11-9 | 2. | Pull out the window glass (with the glass channel attached) toward the top. |
|           | 3. | Remove the bolts attaching the window regulator.                            |
|           | 4. | Take out the window regulator through the service hole.                     |
|           |    |   |

11–6 BODY – Front Door



Fig. 11-13



Fig. 11-14



Fig. 11-15



### INSPECTION



۱۳

Window Regulator

Check the regulator to see if properly lubricated, and apply grease if found insufficient.

Grease the frictional surfaces of the door lock.

Door Lock

ADJUSTMENT Door

the door hinges.

1. Adjust the door in front-rear direction by loosening the bolts attaching the door to

2. Correct surface difference with fender by loosening the bolts attaching the door hinges to the body.



Fig. 11-17



Fig. 11-18



Fig. 11-19



3. If the door does not close properly, correct by adjusting the door lock striker.

1211121 11/1

4. Adjust the window glass tilt.

5. Adjust the outside door handle play.

6. Adjust the inside door handle play.

## REAR DOOR

#### REMOVAL

#### Window Glass and Quarter Window Glass

Remove in the order of the numbers shown.









1. Remove the division bar support by loosening the three attaching bolts.





## WINDSHIELD

#### REMOVAL

#### Windshield Glass

Remove in the order of the numbers shown.

Fig. 11-26







5. After installing the glass, tap it from the ++ outside with the palm of hand so as to settle it down. Fig. 11-36 6. Fill adhesive into the space between the ++ weatherstrip and body, and between the weatherstrip and glass. (1) Place masking tape on the windshield glass and body beforehand so as to allow easy removal of adhesive that had oozed out. Fig. 11-37 (2)Fill in the adhesive from the outside, ++ Fig. 11-38 Install the windshield moulding. 7. ++ Install the wiper arm.

Fig. 11-35

## TAIL GATE

#### TAIL GATE GLASS, REGULATOR, AND TAIL GATE LOCK

#### Removal

Remove in the order of the numbers shown.





#### 11-15



4. Remove the inner and outer weatherstrips, and take out the glass.

Fig. 11-45

Fig. 11-44



5. Disconnect the wire harness.

- Note -

**(= =)** 

Have the battery fusible link disconnected beforehand.

Fig. 11-46



6. Disconnect the connecting rod and spring from the lock off lever.

Fig. 11-47



Regulator removal.
(1) Remove the four bolts.



11–18 BODY– Tail Gate



Connecting Plate Connecting Plate Connecting Plate Utside Handle Lock Off Lever

#### Adjustment

- 1. In case the parts pertaining to the tail gate lock had been removed, pull the tail gate handle and verify that the tail gate lock turns freely.
  - If the tail gate lock does not turn freely; correct by adjusting the length of the connecting rod.
- 2. In case the parts pertaining to the regulator had been removed, verify the lock off lever operation.(1) With the glass lowered all the way down, pulling the tail gate should allow the tail gate lock to turn freely.
  - (2) At conditions other than above, the tail gate handle should be such that it cannot be pulled.
# TAIL GATE ASSEMBLY, HINGE, AND TORSION BAR

- Removal
- 1. Remove the tail gate glass. (Refer to Pg. 11-14).
- 2. Disconnect the battery fusible link, and disconnect the wire harness. (Refer to Fig. 11-45).
- 3. Remove in the order of the numbers shown.

#### Fig. 11-54



#### Fig. 11-55



4. Remove the torsion bar adjust bolt cover.

14



Fig. 11-60



 Remove the tail gate support stay from the tail gate, and take off the tail gate.

Fig. 11-61



8. Remove the hinges from the body.

Fig. 11-62



**9.** Re

**\*\*** 

**\***\*

Remove the torsion cover (1), and pull out the torsion bar (2).

Fig. 11-63



#### Installation

Install by performing the removal in reverse order.

- Note -

When attaching the tail gate to the hinges, insert a wood piece between the torsion bar and body.

Fig. 11-64



Fig. 11-65



Fig. 11-66



Fig. 11-67



#### Adjustment

2. Adjust the tail gate support stay.

3. Adjust the torsion bar.

- 1. Adjust the tail gate alignment and its closing action.

# ROOF HEADLINING

#### REMOVAL

Remove in the order of the numbers shown.

#### Fig. 11-68









# FJ40 SERIES HOOD

Fig. 11-78



#### Fig. 11-79



#### ADJUSTMENT

#### Hood

Adjust the hood in front-rear direction by loosening the nuts at the hood.

#### Fig. 11-80



#### Hood Auxiliary Catch Hook

If the catch hook does not latch on properly, correct by bending the stopper.

#### DOOR

#### REMOVAL

Door Window Glass, Regulator, and Glass Run Remove in the order of the numbers shown.

Fig. 11-81







**\***\*



(2) Take out the regulator.

Fig. 11-89



5. Remove the glass run.

#### 11-31

#### Fig. 11-90



#### Fig. 11-91



# Fig. 11-92



# ADJUSTMENT

#### Door

 Adjust the door in front-rear and vertical directions by loosening the door hinges at the door.

2. Adjust the surface difference with fender and in vertical direction by loosening the door hinges at the body.

3. Correct improper door closure by adjusting the door lock striker.

11-32 BODY - Door



Fig. 11-94



Fig. 11-95



Fig. 11-96



4. Adjust the window glass tilt.

5. Adjust door outside handle play.

6. Adjust door inside handle play.

7. Adjust the door lock.

# BACK DOOR

#### Fig. 11-97





Fig. 11-102



#### Fig. 11-103



#### Fig. 11-104



#### Fig. 11-105



#### ADJUSTMENT

1. Adjust the door alignment by shifting the positions of the door hinges at the body.

Adjust the door closing action.
 (1) Right side door.

(2) Left side door.

#### 3. Adjust the inside handle play.

# BODY ELECTRICAL

| DD | 0 | e |
|----|---|---|
|    | 3 | • |

| FUSE BLOCK 12-2                              |
|--|
| IGNITION SWITCH 12-3                         |
| STARTER SWITCH 12-5                          |
| HEADLIGHT & TAIL LIGHT 12-6                  |
| TURN SIGNAL & HAZARD LIGHT 12-8              |
| TRAILER SOCKET SWITCH 12-13                  |
| WIPER 55 SERIES                              |
| 40 SERIES                                    |
| COMBINATION METER                            |
| FUEL GAUGE & WARTER TEMPERATURE GAUGE… 12-26 |
| OIL PRESSURE GAUGE 12-29                     |
| AMMETER                                      |
| BRAKE WARNING LIGHT 12-31                    |
| FRONT DRIVE VACUUM CONTROL 12-32             |
| POWER WINDOW TAIL GATE 12-38                 |
| HEATER 55 SERIES 12-44                       |
| 40 SERIES 12-51 12                           |

#### FUSE BLOCK





# IGNITION SWITCH

#### REMOVAL

Remove the parts in the order numbered below.

# Fig. 12-2



#### Fig. 12-3



12-3

#### Fig. 12-5



| TERMINAL<br>SWITCH<br>POSITION | АМ | ACC | IG | ST |
|--------------------------------|----|-----|----|----|
| OFF                            |    |     |    |    |
| ACC                            | 0  | 0   |    |    |
| ON                             | 0  | -0  | -0 |    |
| START                          | o— |     | -0 | 0  |

Fig. 12-6



Fig. 12-7



#### INSPECTION



#### INSTALLATION

-----

Perform the removal in reverse order. - Note -

- 1. In installing the ignition w/o switch & key, turn the key to "ACC" and align the convex part with the concave part as shown in Fig. 12-6.
- Install the ignition switch with the convex part aligned against the concave part as shown in Fig. 12-7.

# STARTER SWITCH

# Fig. 12-8



Jæ

Fig. 12-9

LOCK ACC

ON

ST

0-

0-

0-

-0

-0-

-0

-0-

-0



| M ST                           |    |     |   |    |    |  |  |  |  |
|--------------------------------|----|-----|---|----|----|--|--|--|--|
| TERMINAL<br>SWITCH<br>POSITION | АМ | ACC | M | ST | G  |  |  |  |  |
| GLOW                           | 0  |     |   |    | _0 |  |  |  |  |

#### INSPECTION

| Terminal connections |                                  |  |  |  |  |  |  |  |
|----------------------|----------------------------------|--|--|--|--|--|--|--|
| AM                   | To ammeter (–) terminal (Power   |  |  |  |  |  |  |  |
|                      | source)                          |  |  |  |  |  |  |  |
| Μ                    | To fuse (heater) 20A             |  |  |  |  |  |  |  |
|                      | fuse (turn) 15A                  |  |  |  |  |  |  |  |
|                      | fuse (engine) 15A                |  |  |  |  |  |  |  |
| ACC                  | To fuse (wiper) 20A              |  |  |  |  |  |  |  |
| ST                   | To starter relay ''ST'' terminal |  |  |  |  |  |  |  |
|                      | glow plug relay "ST" terminal    |  |  |  |  |  |  |  |
| G                    | To glow plug relay "G" terminal  |  |  |  |  |  |  |  |
|                      |                                  |  |  |  |  |  |  |  |

|    | 0  | -  |
|----|----|----|
| 1  | 1. | -h |
| I. | 2  | J  |



#### Fig. 12-11



| TERMINAL<br>SWITCH<br>POSITION | Тв | ΤL  | PL | Нв | HD |
|--------------------------------|----|-----|----|----|----|
| OFF                            |    | 0   | -0 |    |    |
| 1ST STEP                       | 0  | -0- | 0  |    |    |
| 2ND STEP                       | 0  | -0- | 0  | 0  | 0  |

Fig. 12-12



Fig. 12-13



| I  | NS | P | EC | ст | 1 | O | V |
|----|----|---|----|----|---|---|---|
| Υ. |    |   | 0  |    |   |   |   |

# **Light Switch**

Terminal connections TB .... To fuse (tail) 15A (tail light power

- source) HB .... To fuse (head) 20A (headlight
- power source)
- TL .... To tail light
- PL .... To meter pilot light HD .... To dimmer switch

- Note --

In the vehicles to U.S.A., turning the light switch knob will cause the resistance between TL and PL to change from infinity and 0-10  $\!\Omega.$ 

#### **Dimmer Switch**

Terminal connections

- HD .... To light switch (Power source) HL .... To headlight low beam
- $\mathsf{H}\mathsf{U}$  . . . . To headlight high beam
- HF .... To fuse (head) 20A (headlight flasher)

– Note –

Fig. 12-12 shows terminals for vehicles other than BJ series.

Fig. 12-13 shows terminals for BJ series only.

| TERMINAL<br>SWITCH<br>POSITION | HD | ΗL | HU | HF |
|--------------------------------|----|----|----|----|
| LOW BEAM                       | 0  | _0 |    |    |
| HIGH BEAM                      | 0  |    | 0  |    |
| HEADLIGHT<br>FLASHER           |    |    | 0  | 0  |

### TURN SIGNAL & HAZARD LIGHT

FJ55 vehicles except those with U.S.A. specs.

Fig. 12-14





#### Fig. 12-16



| TERMINAL<br>SWITCH<br>POSITION | B <sub>1</sub> | F | B <sub>2</sub> | L <sub>1</sub> | L <sub>2</sub> | L3 | L <sub>4</sub> |
|--------------------------------|----------------|---|----------------|----------------|----------------|----|----------------|
| OFF                            | 0-             | 0 |                |                |                |    |                |
| ON                             |                | 0 | -0             | 0              | _0             | -0 |                |

#### Fig. 12-17



| TERMINAL<br>SWITCH<br>POSITION | B <sub>1</sub> | F  | 8 <sub>2</sub> | Lı | L2  | L3  | L4  | L5 | L <sub>6</sub> |
|--------------------------------|----------------|----|----------------|----|-----|-----|-----|----|----------------|
| OFF                            | 0-             | φ  |                | 0- |     |     |     |    | 0              |
| ON                             |                | 0- | -0             | 0- | -0- | -0- | -0- | 9  |                |

#### HAZARD SWITCH

#### Inspection

Terminal connections (For vehicles other than U.S.A. specs.)

- B<sub>1</sub> .... To fuse (turn) (turn signal light power source)
- F .... To flasher "B" terminal
- B<sub>2</sub> .... To fuse (stop) (hazard light power source)
- L<sub>1</sub> .... To flasher "L" terminal and turn signal switch "B" terminal
- $L_2 \ \ldots , \ To right side turn signal light$
- $L_3 \ldots$ . To left side turn signal light

| F |    | Terminal | connections | (For | U.S.A. | spec. | vehicles |
|---|----|----------|-------------|------|--------|-------|----------|
|   | U- | only)    |             |      |        |       |          |

- B<sub>1</sub> .... To fuse (turn) (Turn signal light power source)
- F .... To flasher "B" terminal
- B<sub>2</sub> .... To fuse (stop) (hazard light power source)
- L<sub>1</sub> .... To flasher "L" terminal and turn signal switch "B" terminal
- L<sub>2</sub> .... To turn signal switch "RR" terminal and rear right light
- L\_3 .... To turn signal switch ''RL'' terminal and rear left light
- $\mathsf{L}_4$  .... To turn signal switch "FR" terminal and front right light
- $\mathsf{L}_5$  .... To turn signal switch "FL" terminal and front left light
- L<sub>6</sub> .... To flasher "S" terminal

#### BODY ELECTRICAL – Turn Signal & Hazard Light 12 - 11FLASHER Jæ Inspection Flasher without hazard light Terminal connections

Jæ

spec. Vehicles) Terminal connections

source)

B .... To fuse (turn) (power source)

L .... To turn signal switch "TB" terminal

Combined flasher and hazard (Except U.S.A.

B .... To hazard switch "F" terminal (power

L .... To turn signal switch "TB" terminal and hazard switch "L1" terminal.

- Note -

Make sure to ground the flasher body.



Fig. 12-18



В

Fig. 12-20



Combined flasher and hazard (U.S.A. spec. vehicles only)

Terminal connections

B .... To hazard switch "F" terminal (power source)

L .... To turn signal switch "T\_B" terminal and hazard switch "L\_1" terminal

S .... To hazard switch  $L_6$  terminal



0

RIGHT

0

# TRAILER SOCKET SWITCH

INSPECTION

Fig. 12-24



| TERMINAL<br>SWITCH<br>POSITION | 1 | 3 | 5 | 2 | 4 | 6  |
|--------------------------------|---|---|---|---|---|----|
| ON                             | 0 | 0 |   | 0 | 0 |    |
| OFF                            | 0 |   | 0 | 0 |   | -0 |

Terminal connections

- 1 .... To turn signal switch TL terminal
- 2 .... To turn signal switch TR terminal
  3 .... To trailer socket (left side turn signal light)
  4 .... To trailer socket (right side turn signal light)

- 5 .... To rear left turn signal light6 .... To rear right turn signal light

12-13

# WIPER (55 SERIES)

#### REMOVAL

Remove the parts in the order numbered below.

Fig. 12-25



BODY ELECTRICAL – Wiper 12–15

•





# INSPECTION

#### Fig. 12-34



Fig. 12-35



12-17

# WIPER (40 SERIES)

#### REMOVAL

Remove the parts in the order numbered below.






#### 12-20 BODY ELECTRICAL - Wiper

## INSPECTION

Fig. 12-42



Fig. 12-43



Fig. 12-44



### Wiper Motor

Terminal connections

- +1 .... To wiper switch "+1" terminal
  +2 .... To wiper switch "+2" terminal
  B .... To fuse (wiper) (power source)
  S .... To wiper switch "S" terminal

### Wiper Switch

Terminal connections W .... To washer motor (--) .... Ground

| TERMINAL<br>SWITCH<br>POSITION | S | +1  | +2 | _  | w      | Ť   |
|--------------------------------|---|-----|----|----|--------|-----|
| OFF<br>1ST STEP<br>2ND STEP    | 0 | 0 0 | 0  | ٩٩ | 0<br>0 | - 0 |

## COMBINATION METER

### REMOVAL

#### 55 Series

Remove the parts in the order numbered below.

Fig. 12-45





### 40 Series

Remove the parts in the order numbered below.

### Fig. 12-50



## INSPECTION 55 Series



### 40 Series

### Fig. 12-52

### **12V Series**



## FUEL GAUGE & WATER TEMPERATURE GAUGE

### INSPECTION







լթ

Fig. 12-55



Fig. 12-56



Fig. 12-57



Fig. 12-58



- 2. If the above test shows defective condition, remove the combination meter assembly and check on the following points.
  - (1) With the multi-terminal connector plugged in to the combination meter, turn on the ignition switch and verify that battery voltage is present at terminal (A).
  - At the above condition, there should be a constantly varying voltage at terminal (B) that is fluctuating between 2V and 7V.

#### – Note –

When the ignition switch is turned on, the 12V battery voltage will be indicated but after a few seconds, the voltage will drop down to between 2V and 7V.

(3) Measure the resistance between terminals (B) and (C).

Standard resistance 25  $\Omega$ 

Caution —

Do not check the 7V terminal at 12V or 24V.

### Fuel Sender Gauge

Remove the sender gauge and measure the resistance between the terminal and ground with a circuit tester. The resistance should change smoothly when the float arm is moved, and be of the values shown in following table.

55 Series

| Float Position | Resistance ( $\Omega$ ) |
|----------------|-------------------------|
| F              | 17 ± 2.1                |
| 1/2            | 40 ± 4.5                |
| E              | 120 ± 6.5               |

#### 40 Series

| Float Position | Resistance ( $\Omega$ ) |
|----------------|-------------------------|
| F              | 17 ± 2.1                |
| 1/2            | 45 ± 4,5                |
| E              | 120 ± 6.5               |

### 12–28 BODY ELECTRICAL – Fuel Gauge & Water Temperature Gauge

#### Fig. 12-59



Fig. 12-60



Fig. 12-61



Water Temperature Receiver Gauge

 Pull out the connector from the water temperature sender gauge and ground its terminal through a 3.4W bulb. When the ignition switch is turned ON, the bulb should light (but start to flash after few seconds) and the gauge pointer should deflect, if the gauge is in proper condition.

2. If the above test shows defective condition, remove the combination meter assembly and check on the following points.

- With the multi-terminal connector plugged in to the combination meter, turn on the ignition switch and verify that battery voltage is present at terminal (A).
- At the above condition, there should be a constantly varying voltage at terminal (B) that is fluctuating between 2V and 7V.

- Note -

When the ignition switch is turned on, the 12V battery voltage will be indicated but after a few seconds, the voltage will drop down to between 2V and 7V.

(3) Measure the resistance between terminals (B) and (C).

Standard resistance 25  $\Omega$ 

— Caution —

Do not check the 7V terminal at 12V or 24V.

Fig. 12-62



լթ

]

#### Water Temperature Sender Gauge

Measure the resistance between the terminal and ground with a circuit tester. The resistance should vary with the water temperature as shown in the table below.

| Temperature   | Resistance       |
|---------------|------------------|
| 60°C (140°F)  | 90 Ω app.        |
| 80°C (176°F)  | 50 $\Omega$ app. |
| 100°C (212°F) | 27 Ω app.        |
| 105°C (221°F) | 23 <b>Ω</b> app. |

## OIL PRESSURE GAUGE

INSPECTION

Battery

Fig. 12-65

2





լթ

- 2. If the above test shows defective condition, remove the combination meter assembly and check on the following points.
  - (1) With the multi-terminal connector plugged in to the combination meter, turn on the ignition switch and verify that battery voltage is present at terminal (A).
  - (2) Measure the resistance between terminals (A) and (B).

Standard resistance 44 Ω . . . . Except BJ 66 Ω . . . . BJ





### **Oil Pressure Sender Gauge**

Pull out the connector from the sender gauge, and impress battery voltage on the gauge terminal through a 3.4W bulb. The bulb should not light when the engine is stopped, and should flash when the engine is running. The number of flashes should also vary with the engine speed. - Note -

Even when the engine is stopped, the bulb may light for an instant when the battery voltage is impressed, but this is no trouble.

#### Fig. 12-67



Fig. 12-68



### AMMETER

### INSPECTION

յծ

լթ

The ammeter is in good condition if it indicates charging and discharging of the battery. - Note -

The wiring from battery must be connected to the ammeter (+) terminal and the wiring from the alternator and load to the ammeter (-) terminal. If reversed, the ammeter will indicate in reverse direction.

## BRAKE WARNING LIGHT

INSPECTION

Fig. 12-69



## FRONT DRIVE VACUUM CONTROL

OPERATION













## BODY ELECTRICAL - Front Drive Vacuum Control

Jæ

Fig. 12-75



### INSPECTION

### Front Drive Switch

Terminal connections

- B .... To fuse (heater) (power source)
- To front drive relay "1" terminal
   To front drive relay "B" terminal and transfer switch and front drive solenoid "B" terminal.
- L .... To indicator light switch

| TERMINAL<br>SWITCH<br>POSITION | B  | 1 | 2 | L |         | Ť  |
|--------------------------------|----|---|---|---|---------|----|
| OFF                            | 0  | 0 |   | 0 | 9       | -0 |
| ON                             | 0— |   | 0 | 0 | $\odot$ | _0 |



#### BODY ELECTRICAL - Front Drive Vacuum Control 12 - 36





### POWER WINDOW TAIL GATE

INSPECTION





### BODY ELECTRICAL – Power Window Tail Gate

### Fig. 12-82



### Circuit Breaker

Terminal connections

Out of the two terminals, one connects to fusible link (power source) and the other to tail gate relay "B" terminal and tail gate control switch "B" terminal.

| Circuit Breaker Specifications |          |                           |                            |  |  |
|--------------------------------|----------|---------------------------|----------------------------|--|--|
| Ambient Temperature            | Load     | Time for Contacts to Open | Time for Contacts to Closs |  |  |
| 55°C (131°F)                   | 12V, 24A | 2 - 10 sec.               | Within 80 sec.             |  |  |
| 20°C( 68°F)                    | 12V, 24A | 3 13 sec.                 | Within 30 sec.             |  |  |
| 20°C( 68°F)                    | 12V, 20A | Within 60 sec.            | Within 30 sec.             |  |  |



## 12–40 BODY ELECTRICAL – Power Window Tail Gate

| WIRING COLOR<br>CODE<br>SWITCH<br>POSITION | L | L·W | L·B |
|--|---|-----|-----|
| Up   | 0 | 0   |     |
| N  |   |     |     |
| Down                                       | 0 |     | -0  |

## Tail Gate Remote Control Switch

| Ferminal connec | tions |                          |
|-----------------|-------|--------------------------|
| B(L)            |       | To tail gate relay "R"   |
|                 |       | terminal (power sourse)  |
| Up (L · W)      |       | To tail gate motor "Up"  |
|                 |       | terminal and tail gate   |
|                 |       | control switch "Up" ter- |
|                 |       | minal                    |
| Down (L · B)    |       | To tail gate motor       |
|                 |       | "Down" terminal and tail |
|                 |       | gate control switch      |
|                 |       | "Down" terminal.         |

remote control switch "Down" terminal.

Fig. 12-84



| WIRING COLOR<br>CODE<br>SWITCH<br>POSITION | Ĺ  | L - W | L·B |
|--|----|-------|-----|
| Up   | 0  | 0     |     |
| N  |    |       |     |
| Down                                       | 0— |       | _0  |
|  |    |       |     |



### BODY ELECTRICAL – Power Window Tail Gate







### TAIL GATE REGULATOR MOTOR

### Fig. 12-88



Fig. 12-89



### ←→ Rei 1.

- Removal
- 1. Remove the regulator from the tail gate (refer to P11-14).
- 2. Remove the screw and nut from the regulator, and take off the motor.

Fig. 12-90



### Di Re

### Disassembly

Remove the nuts and bolts and disassemble the motor.

### BODY ELECTRICAL – Power Window Tail Gate

Fig. 12-91



#### Assembly

- 1. Fit together the convex and concave parts of the yoke and brush holder.
- 2. The ball will be easier to install if coated with grease.

Fig. 12-92



Fig. 12-93



3. Fit together the protruded and slotted

parts of the end frame and yoke.

4. Assemble the bearing holder to the yoke with the convex part fitted into the concave part.

Fig. 12-94



### Adjustment

Adjust the armature thrust gap with thrust washer and set screw so that it will be in the range of 0.05 to 0.30 mm (0.002 to 0.012 in.)

## HEATER (55 SERIES)



### BODY ELECTRICAL - Heater

### 12-45

### HEATER BLOWER

#### Removal

Remove the parts in the order numbered below.

### Fig. 12-96



**(- -)** 

Fig. 12-97



1. Disconnect the boost ventilator control cable at the heater blower end.

Fig. 12-98



2. Unplug the motor wiring at the connector, remove the three mounting bolts, and take off the blower assembly.

### HEATER RADIATOR

#### Removal

Remove the parts in the order numbered below.

### Fig. 12-99







Drain out the coolant through the radiator drain cock.

12-47



### **HEATER CONTROL & SWITCH**

#### Removal

Remove the parts in the order numbered below.





**\*** 



1. Remove the heater control knob.

|             | BODY ELECTRYCAL – Heater 12–49  |
|-------------|---|
| Fig. 12-107 | 2. Remove the heater switch knob.   |
| Fig. 12-108 | <ul> <li>Remove the three screws attaching the heater control, and take off the heater control together with control cable.</li> </ul>  |
| Fig. 12-109 | <ul> <li>Remove the screw attaching the heater<br/>switch bracket, and take off the heater<br/>switch together with bracket.</li> </ul>   |
| Fig. 12-110 | <b>Adjustment</b><br>After installing the heater or boost ventilator<br>control, make sure to check that it operates<br>properly. If faulty, correct by adjusting the<br>installed position of the cable. |
|             |   |

### 12-50 BODY ELECTRICAL - Heater







# HEATER (40 SERIES)



### 12–52 BODY ELECTRICAL – Heater

### HEATER FRONT BLOWER Fig. 12-115



### HEATER RADIATOR Fig. 12-116



BODY ELECTRICAL - Heater

# INSPECTION









### page

13

| SPECIAL SERVICE TOOL             | 13-2  |
|----------------------------------|-------|
| STANDARD BOLT TIGHTENING TORQUES | 13-10 |
| MAIN PARTS TIGHTENING TORQUES    | 13-12 |
| SERVICE SPECIFICATIONS           | 13-14 |
| LUBRICANT                        | 13-23 |

## SPECIAL SERVICE TOOL

CLUTCH

| Illustration | Tool No.    | Tool Name   |
|--------------|-------------|---|
|              | 09301-55022 | Clutch Guide Tool   |
|              | 09302-25010 | Clutch Pressure Lever Height Gauge                        |
|              | 09303-35010 | Input Shaft Front Bearing Puller<br>(For BJ Series)       |
|              | 09303-55010 | Input Shaft Front Bearing Puller<br>(For FJ, HJ Series)   |
|              | 09304-30012 | Input Shaft Front Bearing Replacer<br>(For BJ Series)     |
|              | 09304-47010 | Input Shaft Front Bearing Replacer<br>(For FJ, HJ Series) |
|              | 09315-00021 | Clutch Release Bearing Remover & Replacer                 |
## SST & SERVICE SPECIFICATIONS – Special Service Tool 13–3

| TRANSMISSION & TRANSF | ER          | (Cont's  |
|-----------------------|-------------|--|
| Illustration          | Tool No.    | Tool Name  |
|                       | 09305-60010 | Gear Shift Lever Remover   |
|                       | 09309-36020 | Transmission Rear Bearing Replacer   |
|                       | 09311-60010 | Counter Gear Needle Roller Guide<br>Shaft<br>(For 3-Speed Transmission)          |
|                       | 09314-36010 | <b>Output Shaft Front Retainer</b><br>(For 4-Speed Transmission)                 |
|                       | 09316-60010 | Transmission & Transfer Bearing<br>Replacer                                      |
|                       | 09318-60011 | <b>Transfer Low Speed Gear Holding</b><br><b>Tool</b><br>(For Transfer)          |
|                       | 09319-60010 | <b>Transfer Idler Gear Shaft Remover</b><br>(For Transfer)                       |
|                       | 09323-60010 | <b>Transfer Guide Shaft</b><br>(For 3-Speed Transmission)                        |
|                       | 09330-00020 | Companion Flange Holding Tool  |
|                       | 09506-35010 | Differential Drive Pinion Rear Bearing<br>Replacer<br>(For 4-Speed Transmission) |
|                       |             |  |

#### TRANSMISSION & TRANSFER (Cont'd)

| Illustration | Tool No.    | Tool Name   |
|--------------|-------------|---|
|              | 09515-21010 | <b>Rear Axle Shaft Bearing Replacer</b><br>(For 4-Speed Transmission) |
|              | 09602-10010 | Front Axle Inner Bearing Puller<br>(For 4-Speed Transmission)         |
|              | 09905-00010 | Snap Ring No.1 Expander   |
|              | 09910-00013 | Puller Set<br>(For 3-Speed Transmission)                              |
|              | 09950-20010 | Universal Puller  |
|              | 09956-00010 | Tightening Piece  |

#### REAR AXLE & DIFFERENTIAL

| Illustration   | Tool No.    | Tool Name   |
|--|-------------|---|
|  | 09330-00020 | Companion Flange Holding Tool                     |
| Contraction of the second seco | 09504-00010 | Differential Side Bearing Adjusting<br>Nut Wrench |

#### SST & SERVICE SPECIFICATIONS – Special Service Tool 13–5

#### REAR AXLE & DIFFERENTIAL (Cont'd)

| Illustration   | Tool No.    | Tool Name  |
|--|-------------|--|
|  | 09505-20010 | Differential Side Bearing Replacer                 |
|  | 09506-35010 | Differential Drive Pinion Rear Bearing<br>Replacer |
| Contraction of the second seco | 09514-35010 | Rear Wheel Bearing Puller                          |
|  | 09515-35010 | Rear Wheel Bearing Replacer                        |
|  | 09530-35010 | Differential Drive Pinion Adjusting<br>Gauge       |
|  | 09607-60020 | Front Wheel Adjusting Nut Wrench                   |
| 00000 H  | 09608-35012 | Axle Hub & Drive Pinion Bearing<br>Tool Set        |
|  | 09950-20011 | Universal Puller                                   |
|  | 09956-00010 | Tightening Piece                                   |

## 13-6 SST & SERVICE SPECIFICATIONS - Special Service Tool

| FR   | ON         | ТΑ | XI | F |
|------|------------|----|----|---|
| 1 11 | <b>UIN</b> |    |    |   |

| Illustration | Tool No.    | Tool Name                                    |  |
|--------------|-------------|--|--|
|              | 09605-60010 | Steering Knuckle Bearing Cup<br>Replacer     |  |
|              | 09606-60010 | Steering Knuckle Bearing Cup<br>Remover      |  |
|              | 09607-60020 | Front Wheel Adjusting Nut Wrench             |  |
|              | 09612-65012 | Steering Worm Bearing Puller                 |  |
|              | 09618-60010 | Front Axle & Drive Shaft Bearing<br>Replacer |  |
|              | 09611-20014 | Tie Rod End Puller                           |  |
|              | 09628-62010 | Ball Joint Puller                            |  |
|              | 09634-60012 | Steering Knuckle Centering Gauge             |  |
|              | 09905-00010 | Snap Ring No.1 Expander                      |  |

#### STEERING

| Illustration                             | Tool No.    | Tool Name   |
|--|-------------|---|
|  | 09307-12010 | <b>Extension Housing Bushing Replacer</b><br>(For Gear Housing Bushing Replace<br>ment) |
| 0000 BB | 09608-35012 | Axle Hub & Drive Pinion Bearing<br>Tool Set   |
|  | 09609-20010 | Steering Wheel Puller   |
|  | 09610-55011 | Pitman Arm Puller   |
|  | 09612-30011 | Steering Worm Bearing Puller  |
|  | 09612-65012 | Steering Worm Bearing Puller  |
|  | 09620-30010 | Steering Gear Box Replacer Set  |
|  | 09611-20014 | Tie Rod End Puller  |
|  | 09628-62010 | Ball Joint Puller   |
|  | 09905-00010 | Snap Ring No.1 Expander   |
|  |             |   |

#### 13-8 SST & SERVICE SPECIFICATIONS – Special Service Tool

| Illustration | Tool No.    | Tool Name  |
|--------------|-------------|--|
|              | 09607-60020 | Front Wheel Adjusting Nut Wrench                 |
|              | 09703-30010 | Brake Shoe Return Spring Tool                    |
|              | 09704-10010 | Brake Adjusting Tool                             |
|              | 09736-30020 | Booster Diaphragm Retainer Remover<br>& Replacer |
|              | 09737-00010 | Brake Booster Push Rod Gauge                     |
|              | 09738-20010 | Booster Overhaul Tool Set                        |
|              | 09738-22012 | Booster Overhaul Tool                            |
|              | 09751-36010 | Brake Tube Union Nut Wrench 10 x<br>12           |
|              | 09753-22011 | Booster Overhaul Stand                           |
|              | 09905-00010 | Snap Ring No. 1 Expander                         |

BRAKE

SST & SERVICE SPECIFICATIONS - Special Service Tool

| FRONT WINCH  | ent.        | TR-                           |
|--------------|-------------|-------------------------------|
| Illustration | Tool No.    | Tool Name                     |
|              | 09325-12010 | Transmission Oil Plug         |
|              | 09330-00020 | Companion Flange Holding Tool |

13–9

#### STANDARD BOLT TIGHTENING TORQUES

9 1 1 1 1 - <u>4 0 6 2 0</u> — Part Number

----- Length of Bolt: 20 mm

— Basic Major Dia, of Thread: 6 mm



Bolt Head Mark\*

\* Bolt Head Mark has the following indications.

#### SPECIFIED TORQUE FOR STANDARD BOLT

| Class | Basic Dia.<br>mm   | Pitch mm   | Standard Torque<br>kg-m (ft-lb)  | Torque Limit kg-m (ft-lb)                            |
|-------|--|--|--|--|
| 4T    | 6<br>8<br>10<br>10<br>12<br>12<br>12<br>13<br>14<br>14<br>16<br>16 | 1<br>1.25<br>1.25<br>1.5<br>1.25 (ISO)<br>1.5<br>1.75<br>1.5<br>1.5<br>2<br>1.5<br>2 | $\begin{array}{cccc} 0.47 & (& 3.4) \\ 1.11 & (& 8.0) \\ 2.25 & (& 16.3) \\ 2.14 & (& 15.5) \\ 4.40 & (& 31.8) \\ 3.89 & (& 28.1) \\ 3.74 & (& 27.0) \\ 5.08 & (& 36.8) \\ 6.33 & (& 45.8) \\ 5.93 & (& 42.8) \\ 9.57 & (& 69.2) \\ 9.10 & (& 65.8) \end{array}$                 | $\begin{array}{rrrrrrrrrrrrrrrrrrrrrrrrrrrrrrrrrrrr$ |
| 5T    | 6<br>8<br>10<br>10<br>12<br>12<br>12<br>13<br>14<br>14<br>16<br>16 | 1<br>1.25<br>1.25<br>1.5<br>1.25 (ISO)<br>1.5<br>1.75<br>1.5<br>1.5<br>2<br>1.5<br>2 | $\begin{array}{cccc} 0.71 & ( & 5.1) \\ 1.66 & ( & 12.0) \\ 3.34 & ( & 24.1) \\ 3.22 & ( & 23.3) \\ 6.60 & ( & 47.7) \\ 5.84 & ( & 42.2) \\ 5.61 & ( & 40.6) \\ 7.63 & ( & 55.2) \\ 9.50 & ( & 68.7) \\ 8.90 & ( & 65.3) \\ 14.36 & ( & 103.8) \\ 13.58 & ( & 98.1) \end{array}$ | $\begin{array}{cccccccccccccccccccccccccccccccccccc$ |
| 6Т    | 6<br>8<br>10<br>10<br>12<br>12<br>12<br>12                         | 1<br>1.25<br>1.25<br>1.5<br>1.25 (ISO)<br>1.5<br>1.75                                | 0.71 ( 5.1)<br>1.66 ( 12.0)<br>3.37 ( 24.0)<br>3.20 ( 23.1)<br>6.60 ( 47.7)<br>5.84 ( 42.2)<br>5.61 ( 40.6)  | $\begin{array}{cccccccccccccccccccccccccccccccccccc$ |

#### SPECIFIED TORQUE FOR STANDARD BOLT

| Class | Basic Dia<br>mm  | Pitch mm   | Standard Torque<br>kg-m (ft-lb)  | Torque Limit kg-m (ft-lb)                            |
|-------|--|--|--|--|
| 7T    | 6<br>8<br>10<br>10<br>12<br>12<br>12<br>13<br>14<br>14<br>14<br>16<br>16 | 1<br>1.25<br>1.25<br>1.5<br>1.25 (ISO)<br>1.5<br>1.75<br>1.5<br>1.5<br>2<br>1.5<br>2 | 0.94 ( 6.9)<br>2.21 ( 16.1)<br>4.49 ( 32.5)<br>4.29 ( 31.0)<br>8.80 ( 63.6)<br>7.78 ( 56.2)<br>7.48 ( 54.1)<br>10.17 ( 73.5)<br>12.67 ( 91.6)<br>11.86 ( 85.8)<br>19.15 (138.5)<br>18.11 (131.0) | $\begin{array}{cccccccccccccccccccccccccccccccccccc$ |

- Note -

The above specified tightening torque is applicable only for female threads in steel material. If the female threads are for materials other than steel, and tightening surface are subjected to heat or vibrations, these specified tightening torque must be reconsidered.

#### 13-12 SST & SERVICE SPECIFICATIONS - Main Parts Tightening Torques

#### TRANSMISSION & TRANSFER

| Location   | kg-m (ft-lb)            |
|--|-------------------------|
| Transmission Case X Transmission Case Cover        | 3.0 - 4.5 (21.7 - 32.6) |
| (For 4-Speed)<br>Transmission Case X Transfer Case | 5 - 8 (36 - 58)         |
| Transmission Case X Clutch Housing                 | 5 - 8 (36 - 58)         |
| Transmission Output Shaft X Nut (For 4-Speed)      | 11 - 14 (80 - 101)      |
| (For 3-Speed)                                      | 14 - 15 (101 - 109 )    |
| Transfer Output Front Shaft X Nut                  | 11 - 14 (80 - 101)      |
| Transfer Case X Parking Brake Backing Plate        | 2 - 3 (14 - 22)         |
| Transfer Output Shaft X Parking Brake Drum X Nut   | 11 - 14 (80 - 101)      |
|  |                         |

#### DIFFERENTIAL

| Location                           | kg-m (ft-lb)              |  |  |
|------------------------------------|---------------------------|--|--|
| Differential Case X Ring Gear      | 10.5 - 12.0 (75.9 - 86.8) |  |  |
| Differential Carrier X Bearing Cap | 9 - 11 (65.1 - 79.6)      |  |  |
| Drive Pinion X Flange X Nut        | 20 - 24 (144 - 173 )      |  |  |

#### REAR AXLE

| Location                        | kg-m (ft-1b)             |
|---------------------------------|--------------------------|
| Rear Axle Shaft X Rear Axle Hub | 2.8 - 4.0 ( 20.3 - 28.9) |
| Rear Axle Housing X Lock Nut    | 8 - 10 (58 - 72)         |

#### FRONT AXLE

| Location  | kg-m (ft-lb)             |
|---|--------------------------|
| Steering Knuckle Arm X Steering Knuckle           | 6 - 7.5 (43 - 54.3)      |
| Steering Knucle X Knuckle Spindle X Backing Plate | 1.5 - 2.2 ( 10.9 - 16.0) |
| Front Axle Hub X Free Wheel Hub Body              | 2.5 - 3.5 ( 18.1 - 25.3) |
| Front Axle Hub X Axle Outer Shaft Flange          | 2.8 - 3.5 ( 20.3 - 25.3) |
| Free Wheel Hub Body X Free Wheel Hub Cover        | 0.4 - 0.7 ( 2.9 - 5.1)   |
| Steering Knuckle Sprindle X Lock Nut              | 8 – 10 (58 – 72)         |

#### STEERING

| Location                                       | kg-m (ft-lb)             |
|--|--------------------------|
| Steering Gear Housing X Gear Housing End Cover | 3.0 - 4.5 ( 21.7 - 32.5) |
| Steering Gear Housing X Sector Shaft End Cover | 3.0 - 4.5 (21.7 - 32.5)  |
| Steering Gear Housing X Gear Housing Bracket   | 4.0 - 5.5 (28.9 - 39.8)  |
| Sector Shaft X Pitman Arm                      | 16.5 - 19.5 (119 - 141 ) |
|  |                          |

#### BRAKE

| Location   | kg-m (ft-lb)              |
|--|---------------------------|
| Transfer Output Shaft X Parking Brake Drum X Nut | 11 - 14 (80 - 101)        |
| Disc Brake Disc X Front Axle Hub                 | 4.0 - 5.5 (28.9 - 39.8)   |
| Disc Brake Caliper X Steering Knuckle            | 7.5 – 10.5 ( 54.2 – 76.0) |

#### FRONT WINCH

| Location  | kg-m (ft-lb)             |
|---|--------------------------|
| Power Take-Off Output Shaft X Universal Joint<br>Flange X Nut | 1.5 - 2.2 ( 10.9 - 15.9) |
| Front Winch Worm Bearing Retainer X Winch Gear<br>Case        | 1.9 - 3.1 (14 - 22)      |

# SERVICE SPECIFICATIONS

## CLUTCH

| Pedal Height<br>(From Asphalt Sheet Top Surface)                 |  | w/Brake Booster<br>mm (in.)                  |                                  | w/o Brake Booster<br>mm (in.)   |                                  |
|--|--|--|----------------------------------|---------------------------------|----------------------------------|
| FJ, HJ, BJ40 Series<br>FJ55 Series                               |  | 215 (8.46)<br>185 (7.28)                     | 215 (8.46) 198<br>185 (7.28) 172 |                                 | 98 (7.80)<br>72 (6.77)           |
| Pedal Play (At Pedal T   | ор)  | mm (in.)                                     |                                  | 0.5-3.0 (0.02-0.12)             |                                  |
| Release Fork Tip Play  | FJ, HJ Series mm (in.)<br>BJ Series mm (in.) |  |                                  | 3 – 4 (0.<br>2 – 3.5 (0.        | 12 – 0.16)<br>08 – 0.14)         |
| Rivet Head Depth Li<br>Clutch Disc<br>Run-Out Limit              |  | mit mm (in.)<br>mm (in.)                     |                                  | 0.3 (0.012)<br>1.0 (0.04 )      |                                  |
| Compression Spring   |  | Installed Length<br>mm (in.)                 | Insta<br>k                       | alled Load<br>ig (Ib)           | Installed Load<br>Limit kg (lb)  |
| HJ Series<br>BJ Series   | Small Spring<br>Large Spring                 | 42.9 (1.689)<br>43.5 (1.713)<br>37.1 (1.461) | 42.5<br>62.2<br>44.6             | 5 (93.5)<br>2 (137)<br>5 (98.3) | 40 ( 88)<br>53 (117)<br>39 ( 86) |
| Clutch Dia Phragm Spring (For FJ Series)<br>Unequal Height Limit |  | mm (in.)                                     | 1.0 (0.04 )                      |                                 | 0.04 )                           |
| Clutch Lever Height (Except FJ Series)                           |  |  |                                  | Standard                        | mm (in.)                         |
| HJ Series<br>BJ Series   |  |  |                                  | 14.2 (0.<br>12.0 (0.            | 559)<br>472)                     |

#### 4-SPEED TRANSMISSION (H41, H42)

|  | Transmission<br>Type | H4<br>(Except<br>Cana | USA &<br>ada)             | H42<br>(For USA &<br>Canada) |  |
|--|----------------------|-----------------------|---------------------------|------------------------------|--|
|  | 1st                  | 4.9                   | 25                        | 3,555                        |  |
| Gear Ratio                                 | 2nd                  | 2,6                   | 43                        | 2.292                        |  |
|  | 3rd                  | 1.5                   | 19                        | 1,410                        |  |
|  | 4th 1.00             |                       | 00                        | 1.000                        |  |
|  | Reverse              | 4.9                   | 25                        | 4.271                        |  |
| Clearance                                  | Standard mn          | n (i <b>n.</b> )      | Limi                      | it mm (in.)                  |  |
| Thrust Clearance, 3rd Gear                 | 0.13-0.28 (0.0051    | -0.0110)              | 0.35                      | 5 (0.0138)                   |  |
| Oil Clearance, 3rd Gear                    | 0.07-0.12 (0.0028    | 3-0.0047              | 0.12                      | 2 (0.0047)                   |  |
| Reverse Idler Gear                         | _                    |                       | 0.16                      | 6 (0.0063)                   |  |
| Synchronizer Ring, 3rd & 4th Gears         | _                    |                       | 0.8                       | (0.032)                      |  |
| Hub Sleeve And Shift Forks                 | _                    |                       | 0.8                       | (0.032)                      |  |
| Reverse Idler Gear Slot And Shift Arm Shoe | _                    |                       | 0.7                       | (0.028)                      |  |
|  |                      |                       | Limit mm (in.)            |                              |  |
| Synchronizer Ring No.1 Dimension           | 1st                  |                       | 2.8                       | (0.110)                      |  |
|  | 2nd                  |                       | 1.8                       | (0.071)                      |  |
| Reverse Shift Arm Shoe Thickness           | Limit mm (           | in.)                  | 8.0                       | (0.319)                      |  |
| Shap Bing Thickness                        | Part No.             |                       | Т                         | hickness                     |  |
|  | or Size Mark         |                       | mm (in.)                  |                              |  |
| Locut Chaft Depring                        | 90520-360            | 15                    | 3,31-3,42                 | (0.1303-0.1346)              |  |
| input shart Bearing                        | 90520-36016          |                       | 3.20-3.31 (0.1260-0,1303) |                              |  |
|  | 0                    |                       | 2.40-2.45                 | (0.0945-0.0965)              |  |
|  | 1                    |                       | 2.45-2.50 (0.0965-0.0984) |                              |  |
| Output Shaft Front                         | 2                    |                       | 2.50-2.55                 | (0.0984-0.1004)              |  |
|  | 3                    |                       | 2.55-2.60                 | (0.1004-0.1024)              |  |
|  | 4                    |                       | 2.60-2.65                 | (0.1024-0.1043)              |  |
|  | 5                    |                       | 2.65-2.70                 | (0.1043-0.1063)              |  |
|  | 0                    |                       | 2.05-2.10 (0.0807-0.0827) |                              |  |
| Counter Shaft Front                        | 2                    |                       | 2.15-2.20 (0.0846-0.0866) |                              |  |
|  | 4                    |                       | 2.25-2.30                 | (0.0886-0.0906)              |  |

#### 3-SPEED TRANSMISSION (J30)

|                                    | 1st                       | 2.757                     |  |
|------------------------------------|---------------------------|---------------------------|--|
| Coor Datio                         | 2nd                       | 1.691                     |  |
| Gear hallo                         | 3rd                       | 1.000                     |  |
|                                    | Reverse                   | 3.676                     |  |
| Clearance                          | Standard mm (in.)         | Limit mm (in.)            |  |
| Thrust Clearance, 2nd Gear         | 0.08-0.23 (0.0032-0.0091) | 0.4 (0.016)               |  |
| Counter Gear                       | 0.05-0.02 (0.0020-0.0079) | 0.4 (0.016)               |  |
| Oil Clearance, 2nd Gear            | -                         | 0.09 (0.0035)             |  |
| Synchronizer Ring, 2nd & 3rd Gears | _                         | 0.8 (0.032)               |  |
| Hub Sleeve And Shift Forks         | -                         | 0.8 (0.032)               |  |
| Snap Ring And Washer Thickness     | Part No.                  | Thickness mm (in.)        |  |
| Input Shoft Dearing                | 90520-33010               | 2.43-2.57 (0.0957-0.1012) |  |
|                                    | 90520-33011               | 2.30-2.42 (0.0906-0.0953) |  |
|                                    | 90520-33132               | 2.35-2.40 (0.0925-0.0945) |  |
| Output Shaft Front                 | 90520-33172               | 2.25-2.30 (0.0886-0.0906) |  |
|                                    | 33441-61010               | 1.45-1.50 (0.0571-0.0591) |  |
| Counter Gear Thrust Washer         | 33442-61010               | 1.50-1.55 (0.0591-0.0610) |  |
|                                    | 33443-61010               | 1.55-1.60 (0.0610-0.0630) |  |

#### TRANSFER

|   | Transfer Type                    | For 3-S     | Speed        | For 4-Speed           |  |  |
|---|----------------------------------|-------------|--------------|-----------------------|--|--|
| Gear Ratio                              | High                             | High 1.000  |              | 1,000                 |  |  |
|   | Low                              | 2.31        | 3            | 1,992                 |  |  |
| Clearance                               | Standard mm (in.) Limit mm (ir   |             | nit mm (in.) |                       |  |  |
| Transfer Idler Gear Thrust              | 0.1-0.3 (0.004-                  | 0.012)      | 0.4          | 4 (0.016 )            |  |  |
| Output Gears Oil Clearance              | 0.035-0.08 (0.00138-0.00         | 1<br>)319)  | 0.0          | 0.09 (0.0040)         |  |  |
| Hub Sleeve And Shift Fork               |                                  | -           |              | 1.0 (0.04 )           |  |  |
| Transfer Output Shaft Bearing           | Preload (While Rotating) kg (lb) |             |              | kg (lb)               |  |  |
| New Bearing                             | 1.2-4.1 (2.6-9.0)                |             |              |                       |  |  |
| Original Bearing                        | Mo                               | ore Than C  | ).47 (1.0    | )4)                   |  |  |
| Thrust Spacer And Adjust Shim Thickness | Part No.                         |             | Thick        | (in.)                 |  |  |
|   | 36261-6001                       | 36261-60010 |              | 1.2-1.3 (0.047-0.051) |  |  |
| Idler Gear Thrust Spacer                | 36262-6001                       | 36262-60010 |              | 1.3-1.4 (0.051-0.055) |  |  |
|   | 36263-6001                       | 36263-60010 |              | 1.4-1.5 (0.055-0.059) |  |  |
|   | 90564-6401                       | 17          | 0.1          | 10 (0.0039)           |  |  |
| Output Chaft Despise Adjust Chim        | 90564-6402                       | 90564-64023 |              | 0.15 (0.0059)         |  |  |
|   | 90564-6402                       | 90564-64024 |              | 0.20 (0.0079)         |  |  |
|   | 90564-6402                       | 25          | 0.2          | 25 (0.0098)           |  |  |
| 1                                       |                                  |             | 1            |                       |  |  |

#### PROPELLER SHAFT

| Spider Thrust Play         | mm (i <b>n.</b> ) | Less Than                    | 0.05 (0.002)                 |
|----------------------------|-------------------|------------------------------|------------------------------|
|                            |                   | Part No.                     | Thickness mm (in.)           |
| Spider Snap Ring Thickness | 90520-29286       | 1.48-1.53<br>(0.0583-0.0602) |                              |
|                            |                   | 90520-29287                  | 1.53-1.58<br>(0.0602-0.0622) |
|                            |                   | 90520-29288                  | 1.58-1.63<br>(0.0622-0.0642) |

## 13-18 SST & SERVICE SPECIFICATIONS – Service Specifications

#### DIFFERENTIAL

|   |   | Except USA And Canada   |  | 3.700  |   |
|---|---|---|--|--|---|
| Gear Ratio                                      |   | (Except USA And Canada OPT)   |  | 4.111  |   |
| Backlash  |   |   |  | Standard mm (  | in.)                                      |
| Pinion Gear or Side Gear<br>Ring Gear           |   | 0.02-0.20 (0.0008-0.00<br>0.15-0.20 (0.0059-0.00  |  | ).0079)<br>).0079)   |   |
| Rear Axle Shaft End Clearance                   |   | Standard mm (   | in.)   | 0.016-0.46 (0.0  | 0006-0,0181)                              |
| Ring Gear Run-Out                               |   | Limit mm (in.   | .)   | 0.1 (0   | .004)                                     |
| Preload (Starting)                              |   | New Bearin  | ng   | Original   | Bearing                                   |
| Drive Pinion Bearing<br>Total Preload           | kg-cm (in-lb)<br>kg-cm (in-lb)  | 19-26 (16.5<br>4-6 (3.5-5.2)  | 5-22.6)<br>) + Drive   | 9-13 (7<br>Pinion Preload  | .8-11.3)                                  |
| Washer, Spacer And Shim Thickne                 | SS  | Part No.  |  | Thickness r  | nm (in.)                                  |
| Side Gear Thrust Washer                         | ar Thrust Washer 41361-35010<br>41362-35010<br>41363-35010<br>41364-35010                     |   | 1.60 (0.063)<br>1.75 (0.069)<br>1.90 (0.075)<br>2.05 (0.081) |  |   |
| Pinion Shaft Spacer                             |   | 41344-35010<br>41345-35010<br>41346-35010<br>41347-35010<br>41348-35010   |  | 29.8 (1,<br>30.2 (1,<br>30.6 (1,<br>29.0 (1,<br>29.4 (1,   | .173)<br>.189)<br>.204)<br>.142)<br>.157) |
| Drive Pinion Adjusting Shim<br>(For Protrusion) | ion Adjusting Shim<br>Protrusion)<br>90564-70102<br>90564-70103<br>90564-70104<br>90564-70121 |   | 0.25 (0.<br>0.30 (0.<br>0.35 (0.<br>0.45 (0.<br>0.40 (0.     | .0098)<br>.0118)<br>.0138)<br>.0177)<br>.0158)   |   |
| Drive Pinion Adjusting Shim<br>(For Prelord)    | Drive Pinion Adjusting Shim<br>(For Prelord)  |   | 90564-30035  |  | .0098)                                    |
| Drive Pinion Adjusting Washer<br>(For Prelord)  |   | 90560-30184         2.75 (0)           90560-30185         2.78 (0)           90560-30186         2.81 (0)           90560-30187         2.84 (0)           90560-30188         2.87 (0)           09560-30188         2.87 (0)           09560-30190         2.90 (0)           09560-30191         2.93 (0)           09560-30192         2.96 (0)           90560-30199         2.99 (0) |  | .1083)<br>.1094)<br>.1106)<br>.1118)<br>.1130)<br>.1130)<br>.1142)<br>.1154)<br>.1165)<br>.1177) |   |

| 13- | _19 |
|-----|-----|
| 10  | 10  |

| F | R | 0 | N | Т | AXLE |  |
|---|---|---|---|---|------|--|
|---|---|---|---|---|------|--|

| Steering Knuckle Bearing                     | Standard kg (lb)  |                           |
|--|-------------------|---------------------------|
| Preload (While Rotating)                     | 1.8-2.3 (3.9-5.0) |                           |
|  | Part No.          | Thickness mm (in.)        |
| Steering Knuckle Adjusting Shim Thickness    | 43233-60010       | 0.2 (0.008)               |
|  | 43234-60010       | 0.5 (0.020)               |
|  | 43233-60020       | 1.0 (0.040)               |
| Free Wheel                                   | Limit mm (in.)    |                           |
| Free Wheel Hub Inner To Hub Ring Oil Clearan | 0.3 (0.012)       |                           |
| Front Wheel Alignment                        |                   |                           |
| Toe-In                                       | 3-5 mm (          | (0.12-0.2 in.)            |
| Camber                                       | 1                 | 0                         |
| Caster                                       | 0                 |                           |
| King Pin Inclination                         | 30'               |                           |
|  | Inside 3          | 2° (26° For 9.00-15 Tire) |
| Steering Angle                               | Outside 3         | 0° (24° For 9.00-15 Tire) |

#### 13-20 SST & SERVICE SPECIFICATIONS – Service Specifications

#### STEERING

| Gear Ratio  |  |                                      | 23.5                     |  |  |
|---|--|--------------------------------------|--------------------------|--|--|
| Steering Wheel Free Play  | 0 – 25 mm (0 – 0.98 in.)   |                                      |                          | 8 in.)   |  |
| Clearance   | Standard mm (  | (in.)                                |                          | Limit mm (in.)   |  |
| Sector Shaft Oil<br>Sector Shaft Thrust                           | 0,009-0,060<br>(0,0004-0,0024<br>—   | 1)                                   |                          | 0.1 (0.004)<br>0.1 (0.004)   |  |
| Preload (Starting)  |  |                                      | Sta                      | ndard kg (lb)  |  |
| Worm Bearing w/o Sector Shaft<br>w/ Sector Shaft Preload          |  |                                      | 4.0- 6<br>8.0-1 <i>1</i> | 5.0 ( 8.8-13.2)<br>1.0 (17.6 24.2)   |  |
| Length  |  |                                      | Star                     | ndard mm (in.)   |  |
| Steering Relay Rod<br>Tie-Rod<br>Steering Drag Link (Except FJ55) |  |                                      |                          | 827 (32,56)-<br>1205 (47,44)<br>855 (33,66)  |  |
|   | Part No.   |                                      | Thi                      | ckness mm (in.)  |  |
| Intermediate Shaft Snap Ring Thickness<br>(For FJ55 Series)       | 90521-22011<br>90521-22012<br>90521-22013  |                                      |                          | 1.20 (0.0424)<br>1.25 (0.0492)<br>1.30 (0.0512)  |  |
| Washer And Shim Thickness   | Part No.   | Mark                                 |                          | Thickness<br>mm (in.)  |  |
| Sector Shaft Thrust Washer  | 45352-36010<br>45353-36010<br>45354-36010<br>45355-36010<br>45356-36010  | 1<br>2<br>3<br>4<br>5                |                          | 2.00 (0.0787)<br>2.05 (0.0807)<br>2.10 (0.0827)<br>2.15 (0.0846)<br>2.20 (0.0866)  |  |
| End Cover Shim<br>(For Worm Bearing Preload)                      | 45323-36010<br>45323-36020<br>45323-36030<br>45323-36040<br>45323-36050<br>45323-36060<br>45323-36070<br>45323-36080 | 1<br>2<br>3<br>4<br>5<br>6<br>7<br>8 |                          | 0.05 (0.0020)<br>0.07 (0.0028)<br>0.08 (0.0031)<br>0.10 (0.0039)<br>0.20 (0.0079)<br>0.50 (0.0197)<br>0.06 (0.0024)<br>0.09 (0.0035) |  |

#### BRAKE

| Master & Wheel Cylinder Inner Diameter Standard<br>mm (in.)   | 40<br>Series   | 2<br>Se                     | 15<br>ries                                 | 43, 55<br>Series                                     |  |
|---|--|-----------------------------|--|--|--|
| Single Master Cylinder<br>Tandem Master Cylinder<br>Tandem Master Cylinder<br>(For U.S.A. And Canada)<br>Front Wheel Cylinder | 25.4 (1.0000)<br>25.4 (1.0000)<br>22.22 (0.8748)<br>31.75 (1.2500) | 28.57 (<br>28 <b>.</b> 57 ( | ←<br>1.1248)<br>1 <b>.1</b> 248)<br>←      | ←<br>25.4 (1.0000)<br>22.22 (0.8748)<br>←            |  |
| Front Disc Brake Caliper<br>Rear Wheel Cylinder   | 42.85 (1.6870)<br>& 33.96 (1.3370)<br>22.22 (0.8748)               |                             | 1.1220)                                    | 42.85 (1.6870)<br>& 33.96 (1.3370)<br>23.81 (0.9374) |  |
| Pedal Height<br>(From Asphalt Sheet Top Surface)  | w/Brake Boo<br>mm (in.)  | stér                        | w/B  | rake Booster<br>mm (in.)                             |  |
| FJ, HJ, BJ40 Series<br>FJ55 Series  | 215 (8.46<br>185 (7.28   | )                           | 1  | 98 (7.80)<br>72 (6.77)                               |  |
| Pedal Play (At Pedal Top) mm (in.)  |  | 3                           | 3 — 6 (0.1                                 | 2 - 0.23)  |  |
| Pedal Reserve Distance FJ, HJ, BJ40 Series<br>FJ55 Series   | s mm (in.)<br>mm (in.)   |                             | More Than 80 (3.15)<br>More Than 70 (2.76) |  |  |
| Parking Brake Lever Travel  | Standard 7 –   |                             |  | 12 Notches   |  |
| Adjustment  | Number (   | Of Notch                    | es To Be                                   | Returned   |  |
| Foot Brake<br>Parking Brake   |  | 4 5 M<br>1 2 M              | Notches<br>Notches                         |  |  |
| Lining Thickness<br>Foot & Parking Brake Lining Limit mm (in.)  |  |                             |  | 1.5 (0.06)   |  |
| Front Drum Inner Diameter Limit mm (in.)  |  |                             | 2  | 297 (11.70)  |  |
| Rear Drum Inner Diameter Limit mm (in.)<br>FJ45, HJ45 & F   | J55 Fire Truck   |                             | 2  | 297 (11.70)  |  |
| Except FJ45, H.   | J45 & FJ55 (Fire T   | ruck)                       | 2  | 292 (11.50)  |  |
| Disc Brake Pad Thickness  | Standard mm  | (in.)                       | Lin  | nit mm (in.)   |  |
|   | 10 (0.39)  |                             |  | 1 (0.04)   |  |
| Disc Brake Disc Thickness   | Standard mm  | (in.)                       | Lin  | nit mm (in.)   |  |
|   | 20 (0.79)  |                             |  | 19 (0.74)  |  |
| Disc Brake Disc Runout  | Limi   | t mm                        | (in.)                                      | 0.12 (0.005)   |  |
| Booster Push Rod To Master Cylinder Piston Clearad<br>(Without Vacuum)  | nce Standard<br>mm (in.)   |                             | 0.0<br>(0.0                                | 0.6 — 0.65<br>024 — 0.026)                           |  |

#### SST & SERVICE SPECIFICATIONS – Service Specifications 13-22

 $\bar{c}$ 

#### BRAKE (Cont'd)

| Vacuum Pump                                 | Limit mm (in.)                                |
|---|---|
| Rotor To Spline Shaft Play (On Rotor)       | 2.4 (0.095)                                   |
| Pump Casing Inner Diameter                  | 58.19 (2.291 )                                |
| Pump Drive End Frame Bushing Inner Diameter | 16.14 (0.6354)                                |
| Pump Blad Heigh<br>Width<br>Length          | 12 (0.47 )<br>6.92 (0.272 )<br>34.98 (1.377 ) |

#### FRONT WINCH

|  | Part No.    | Thickness mm (in.) |
|--|-------------|--------------------|
| Winch Worm Bearing Prelord Adjusting Shim<br>Thickness | 38123-60010 | 0.228 (0.009)      |
|  | 38124-60010 | 0.5 (0.020)        |

| LUBRICANT                               |   |             |        |                   |  |  |
|---|---|-------------|--------|-------------------|--|--|
| Dischard                                |   | Oil Capacit | y      |                   |  |  |
| Place Used                              | Liter   | US qt       | Imp.qt | Classification    |  |  |
| Transmission 4-Speed                    | 3.'1  | 3.3         | 2.7    |                   |  |  |
| 3-Speed                                 | 1.7   | 1.8         | 1.5    | SAE90, API GL-4   |  |  |
| Transfer                                | 1.7   | 1.8         | 1.5    |                   |  |  |
| Front Differential<br>FJ, BJ, HJ Series | 2.5   | 2.6         | 2.2    |                   |  |  |
| Rear Differential<br>FJ40 & BJ40        | 2.4   | 2.6         | 2.1    | SAEQO APL CL - 5  |  |  |
| FJ43 & BJ43                             | 2.7   | 2.9         | 2.4    | 3AL90, AFT GL=5   |  |  |
| FJ45, HJ45 & FJ55                       | 2.9   | 3.1         | 2.6    |                   |  |  |
| Steering                                | 0.6   | 0.6         | 0.5    |                   |  |  |
| Front Winch                             | 0.6   | 0.6         | 0.5    | 5AE90, AFT GL-4   |  |  |
| Ball Joint & Propeller Shaft Spic       | ler Grease  |             |        | NLGI No.1 or No.2 |  |  |
| Wheel Bearing Grease                    |   |             |        | NLGI No.2         |  |  |
| Steering Knuckle & Axle Shaft (         | Molybdemum Disulphide<br>Lithium Base Grease                    |             |        |                   |  |  |
| Brake Fluid                             | For USA : DOT 3<br>Other : DOT 3 or<br>SAEJ 1703<br>(SAE 70R-3) |             |        |                   |  |  |

| GRIDE                               | COMPONENTS  | GRIDE                               | COMPONENTS  |
|-------------------------------------|---|-------------------------------------|---|
| E-2<br>C-4<br>C-20                  | ALTERNATOR<br>AMMETER<br>ANTENNA (OPT)  | E-6<br>E-6                          | MOTORS:<br>HEATER BLOWER, FRONT (OPT)<br>HEATER BLOWER, REAR (OPT)  |
| D-4                                 | BATTERY   | C-2<br>C-21                         | VINDSHIELD WASHER (OPT)   |
| C-19<br>C-4                         | CIGARETTE LIGHTER (OPT)<br>COMBINATION METER  | G-21<br>E-4                         | OIL PRESSURE GAUGE  |
| G-23                                | DISTRIBUTOR   | E-5                                 |   |
|                                     | EMISSION CONTROL SYSTEM   | F-2                                 | REGULATOR   |
| E-22<br>G-22<br>D-22                | (For ECE No. 15):<br>EMISSION CONTROL COMPUTER<br>SPEED SENSOR<br>VACUUM SWITCHING VALVE      | F-8<br>C-12                         | RELAYS:<br>FRONT DRIVE (OPT)<br>HORN  |
| D-14                                | FLASHER, TURN SIGNAL & HAZARD   | E-21                                | SPEAKER (OPT)   |
| C-23<br>F-4<br>G-5<br>B-4<br>C-4    | FUEL CUT SOLENOID<br>FUEL GAUGE<br>FUEL SENDER<br>FUSE BOX<br>FUSIBLE LINK                    | C-8<br>F-9<br>D-18<br>F-8           | SWITCHES:<br>BACK-UP LIGHT<br>BRAKE WARNING LIGHT (OPT)<br>DIMMER<br>FRONT DRIVE (OPT)                      |
| G-12                                | HORNS, LO - HI  | E-8<br>C-13                         | FRONT DRIVE INDICATOR LIGHT   |
| E-23<br>F-20                        | IGNITION COIL<br>INSPECTION LIGHT SOCKET  | C-6<br>E-11<br>B-2                  | HEATER BLOWER MOTOR (OPT)<br>HORN<br>IGNITION   |
| G-9<br>E-17<br>G-19<br>E-19<br>E-20 | LIGHTS:<br>BACK-UP, LH · RH<br>COMBINATION METER<br>HEADLIGHT, LH · RH<br>HIGH BEAM INDICATOR | E-20<br>C-17<br>E-9<br>E-10<br>F-16 | INTERIOR LIGHT<br>LIGHT CONTROL<br>PARKING BRAKE (OPT)<br>STOP LIGHT<br>TRAILER SOCKET CHANGE OVER<br>(OPT) |
| D-16                                | LICENSE PLATE   | C-7                                 | TRANSFER INDICATOR (OPT)  |
| C-9<br>D-15                         | PARKING BRAKE (OPT)<br>PARKING, FRONT   | E-14<br>E-21                        | WINDSHIELD WIPER AND WASHER   |
| G-13<br>G-10                        | SIDE TURN SIGNAL  | F-17                                | TRAILER SOCKET  |
| G-17<br>F-13                        | TAIL, LH · RH<br>TURN SIGNAL, FRONT, LH · RH  | G-7                                 | VACUUM SWITCHING SOLENOID (OPT)   |
| G-15<br>H-14                        | TURN SIGNAL, REAR, LH RH<br>TURN SIGNAL INDICATOR, LH RH                                      | E-4<br>F-5                          | WATER TEMPERATURE GAUGE<br>WATER TEMPERATUR SENDER  |

LAND CRUISER (FJ40, 43, 45) ELECTRICAL WIRING DIAGRAM (Except U.S.A & CANADA) No. 98878

- Note -

 Note –
 When reading the wiring diagram, following should be noted.
 1. WIRING COLOR CODE IS SHOWN WITH ALPHABETICAL LETTER/S. THE FIRST LETTER INDICATES THE BASIC COLOR FOR THE WIRE, AND THE SECOND LETTER INDICATES THE SPIRAL LINE COLOR. B = BLACK O = ORANGE W = WHITE W = WHITE

| В | ~ B | LA |    |  |
|---|-----|----|----|--|
| G | = ( | RE | ΕN |  |

O = ORANGE R = RED

Y = YELLOW

L = LIGHT BLUE EXAMPLE : RG, IS FOR RED AND A GREEN LINE. LEGEND IN THE BRACKET [ ] OF THE WIRING DIAGRAM SHOWS THE GRID LOCATION OF MATING 2. CONNECTION. BROKEN LINES IN THE WIRING DIAGRAM ARE FOR VARIED MODELS OR OPTIONAL EQUIPMENT.

3.









| GRIDE<br>LOCATION  | COMPONENTS   | GRIDE                      | COMPONENTS   |
|--------------------|--|----------------------------|--|
| G-2<br>C-5<br>C-20 | ALTERNATOR<br>AMMETER (Except Tandem)<br>ANTENNA (OPT)<br>BATTERY        | E-8<br>C-2<br>G-4<br>C-21  | HEATER BLOWER REAR (OPT)<br>STARTER<br>TAIL GATE<br>WINDSHIELD WASHER (OPT)      |
| 0-0                |  | F-21                       | WINDSHIELD WIPER   |
| D-22<br>E-4<br>C-5 | CIGARETTE LIGHTER (OPT)<br>CIRCUIT BREAKER<br>COMBINATION METER          | E-5<br>E-6                 | OIL PRESSURE GAUGE<br>OIL PRESSURE SENDER  |
| D-4                | DISTRIBUTOR  | D-20                       | RADIO (OPT)  |
| G-23               | EMISSION CONTROL SYSTEM:<br>SPEED SENSOR (For ECE)                       | E-2<br>F-2                 | REGULATOR (For Tandem)<br>REGULATOR (Except Tandem)                              |
| E-23<br>G-23       | THROTTLE POSITION COMPUTER (For ECE)<br>VACUUM SWITCHING VALVE (For ECE) | F-9<br>C-13                | RELAYS:<br>FRONT DRIVE (OPT)<br>HORN   |
| C-24               | FUEL CUT SOLENOID (For ECE)  | F-4                        | TAIL GATE  |
| G-5                | FUEL GAUGE   | E-20                       | SPEAKER (OPT)  |
| G-6<br>B-5<br>C-3  | FUEL SENDER<br>FUSE BOX<br>FUSIBLE LINK                                  | C-11<br>E-12               | SWITCHS:<br>BACK-UP LIGHT<br>BRAKE WARNING (For Tandem)                          |
| E-13               | HORNS, LO-HI   | E-19                       | DIMMER   |
| D-4<br>G-22        | IGNITION COIL<br>INSPECTION LIGHT SOCKET                                 | E-10<br>D-10<br>D-15       | FRONT DRIVE (OPT)<br>FRONT DRIVE INDICATOR LIGHT (OPT)<br>HAZARD WARNING LIGHT   |
| G-11<br>C-12       | LIGHTS:<br>BACK-UP, LH.RH<br>BRAKE WARNING INDICATOR<br>(For Tandem)     | C-18<br>E-7<br>D-8<br>F-14 | LIGHT CONTROL<br>HEATER BLOWER, FRONT (OPT)<br>HEATER BLOWER, REAR (OPT)<br>HORN |
| G-19               | COMBINATION METER  | B-2                        | IGNITION   |
| D-5                | DISCHARGE WARNING (For Tandem) )   | G-22                       | INTERIOR LIGHT   |
| E-10               | FRONT DRIVE INDICATOR  | D-12                       | PARKING BRAKE (For Tandem)   |
| G-20               | HEADLIGHT, LH.RH   | C-13                       | STOP LIGHT   |
| G-22               |  | G-4                        | TAIL GATE CONTROL  |
| F-18               | LICENSE PLATE  | F-5                        |  |
| F-18               | PARKING FRONT  | F.16                       | TRAL ER SOCKET CHANCEOVER (OPT)  |
| G-13               | STOP, LH. RH   | C-9                        | TRANSFER INDICATOR (OPT)   |
| G-18               | TAIL, LH.RH  | E-15                       | TURN SIGNAL  |
| F-15               | TURN SIGNAL, FRONT, LH.RH  | D-21                       | WINDSHIELD WIPER AND WASHER  |
| F-17               | TURN SIGNAL, REAR, LH.RH   | D-17                       | TRAILER SOCKET (OPT)   |
| G-15               | TURN SIGNAL, INDICATOR, LH.RH  | 0.17                       |  |
| G-15               | TURN SIGNAL, SIDE, LH.RH   | G-9                        | VACUUM SWITCHING SOLENOID (OPT)  |
| C-7                | MOTORS:<br>HEATER BLOWER, FRONT (OPT)                                    | F-5<br>F-6                 | WATER TEMPERATURE GAUGE<br>WATER TEMPERATURE SENDER                              |

LAND CRUISER (FJ55 Series) ELECTRICAL WIRING DIAGRAM (Except U.S.A & CANADA) No.98878

•

Note:

10 1979 B

When reading the wiring diagram, following should be noted.
1. WIRING COLOR CODE IS SHOWN WITH ALPHABETICAL LETTER/S. THE FIRST LETTER INDICATES THE BASIC COLOR FOR THE WIRE, AND THE SECOND LETTER INDICATES THE SPIRAL LINE COLOR.

| B = BLACK | O = ORANGE | W = WHITE  |
|-----------|------------|------------|
| G = GREEN | R = RED    | Y = YELLOW |
|           |            |            |

L = LIGHT BLUE EXAMPLE: RG, IS FOR RED AND A GREEN LINE 2. LEGEND IN THE BRACKET [ ] OF THE WIRING DIAGRAM SHOWS THE GRID LOCATION OF MATING CONNECTION. BROKEN LINES IN THE WIRING DIAGRAM ARE FOR VARIED MODELS OR OPTIONAL EQUIPMENT.

3.









| GRIDE   | COMPONENTS  | GRIDE   | COMPONENTS   |
|---|---|---|--|
| F-3   | ALTERNATOR  | D-6   | OIL PRESSURE GAUGE   |
| C-6   | AMMETER   | E-7   | OIL PRESSURE SENDER  |
| C-24  | ANTENNA (OPT)   | E-4   | OVER INJECTION MAGNET  |
| D-4   | BATTERY   | C-23  | RADIO (OPT)  |
| C-20<br>C-6   | CIGARETTE LIGHTER(OPT)<br>COMBINATION METER   | E-3   | REGULATOR  |
| D-15<br>F-6<br>F-7<br>E-6<br>C-4  | FLASHER, TURN SIGNAL<br>FUEL GAUGE<br>FUEL SENDER<br>FUSE BOX<br>FUSIBLE LINK   | F-9<br>E-4<br>C-13<br>D-2   | RELAYS:<br>FRONT DRIVE (OPT)<br>GLOW PLUG<br>HORN<br>STARTER   |
| G-5<br>F-5  | GLOW PLUG<br>GLOW PLUG CONTROLLER   | E-23  | SPEAKER (OPT)  |
| F-13  | HORNS, LO-HI  | D-7<br>F-11<br>E-18<br>E-10<br>D-11<br>D-15<br>C-8<br>E-13<br>C-21<br>C-17<br>D-11<br>B-2<br>D-12<br>C-10<br>E-15<br>E-22 | SWITCHES:<br>BACK-UP LIGHT<br>BRAKE WARNING (OPT)<br>DIMMER<br>FRONT DRIVE (OPT)<br>FRONT DRIVE INDICATOR LIGHT<br>(OPT)<br>HAZARD WARNING LIGHT (OPT)<br>HEATER BLOWER (OPT)<br>HORN<br>INTERIOR LIGHT<br>LIGHT CONTROL<br>PARKING BRAKE (OPT)<br>STARTER<br>STOP LIGHT<br>TRANSFER INDICATOR (OPT)<br>TURN SIGNAL<br>WINDSHIELD WIPER AND WASHER |
| E-20  | INSPECTION LIGHT SOCKET   |   |  |
| G-7<br>G-18<br>G-19<br>E-19<br>C-21<br>E-18<br>D-12<br>E-16<br>G-12<br>G-17<br>F-15<br>G-15<br>H-15<br>G-15 | LIGHTS:<br>BACK-UP, LH.RH<br>COMBINATION METER PILOT<br>HEADLIGHT, LH.RH<br>HIGH BEAM INDICATOR<br>INTERIOR<br>LICENSE PLATE<br>PARKING BRAKE (OPT)<br>PARKING, FRONT<br>STOP, LH.RH<br>TAIL, LH.RH<br>TURN SIGNAL, FRONT, LH.RH<br>TURN SIGNAL, REAR, LH.RH<br>TURN SIGNAL, INDICATOR, LH.RH<br>TURN SIGNAL, SIDE, LH.RH |   |  |
| E-8<br>C-4  | MOTORS :<br>HEATER BLOWER (OPT)<br>STARTER  | G-9   | VACUUM SWITCHING SOLENOID (OPT)  |
| G-22<br>G-22  | WINDSHIELD WASHER (OPT)<br>WINDSHIELD WIPER   | E-6<br>E-7  | WATER TEMPERATURE GAUGE  |

#### LAND CRUISER (HJ45) ELECTRICAL WIRING DIAGRAM (Except U.S.A & CANADA) No. 98880

Note:

When reading the wiring diagram, following should be noted.

1. WIRING COLOR CODE IS SHOWN WITH ALPHABETICAL LETTER/S.

THE FIRST LETTER INDICATES THE BASIC COLOR FOR THE WIRE, AND THE SECOND LETTER INDICATES THE SPIRAL LINE COLOR. W = WHITE

B = BLACK G = GREEN L = LIGHT BLUE

O = ORANGE R = RED

Y = YELLOW

EXAMPLE : RG, IS FOR RED AND A GREEN LINE. LEGEND IN THE BRACKET [ ] OF THE WIRING DIAGRAM SHOWS THE GRID LOCATION OF MATING 2. CONNECTION.

BROKEN LINES IN THE WIRING DIAGRAM ARE FOR VARIED MODELS OF OPTIONAL EQUIPMENT. 3.








| GRIDE<br>LOCATION   | COMPONENTS  | GRIDE<br>LOCATION   | COMPONENTS  |
|---|---|---|---|
| F-3<br>C-6<br>C-20  | ALTERNATOR<br>AMMETER<br>ANTENNA (OPT)  | D-6<br>D-7<br>D-4   | OIL PRESSURE GAUGE<br>OIL PRESSURE SENDER<br>OVER INJECTION MAGNET  |
| D-4   | BATTERY   | C-20  | RADIO (OPT)   |
| E-22<br>C-6   | CIGARETTE LIGHTER (OPT)<br>COMBINATION METER  | E-3<br>E-9  | REGULATOR<br>RESISTOR<br>(For Front Drive Indicator Switch)   |
| D-22<br>F-23<br>G-23<br>D-23  | EDIC CONTROLLER ASSY.<br>EDIC RELAY ASSY. '<br>EDIC MOTOR ASSY.<br>ENGINE SPEED SENSOR  | D-16<br>D-22<br>D-23<br>E-23  | RESISTOR (For Light Control Switch)<br>RESISTOR (For Cigarette Lighter)<br>RESISTOR (ForEDIC Controller)<br>RESISTOR (ForEDIC Controller)   |
| D-14<br>F-6<br>E-7<br>B-6<br>C-4  | FLASHER, TURN SIGNAL<br>FUEL GAUGE<br>FUEL SENDER<br>FUSE BOX<br>FUSIBLE LINK   | F-8<br>E-4<br>C-12<br>C-2   | RELAYS:<br>FRONT DRIVE (OPT)<br>GLOW PLUG<br>HORN<br>STARTER  |
| G-4   | GLOW PLUG   | D-20  | SPEAKER (OPT)   |
| F-5   | GLOW PLUG CONTROLLER  | C-10  | SWITCHES:<br>BACK-UP LIGHT  |
| F-13  | HORNS, LO-HI  | F-11  | BRAKE WARNING (OPT)   |
| C-23  | INSPECTION LIGHT SOCKET   | F-22  | COLD START  |
| G-10<br>D-18<br>D-15<br>G-9<br>G-19<br>E-20<br>G-21<br>D-17<br>C-17<br>C-17<br>C-11<br>D-16<br>G-12<br>G-17<br>F-14<br>G-15<br>H-14<br>G-14 | LIGHTS:<br>BACK-UP, LH.RH<br>COMBINATION METER PILOT<br>FOG LIGHT (Except ECE OPT)<br>FRONT DRIVE INDICATOR (OPT)<br>HEADLIGHT, LH.RH<br>HIGH BEAM INDICATOR<br>INTERIOR<br>LICENSE PLATE<br>LIGHT CONTROL SWITCH<br>PARKING BREAK (OPT)<br>PARKING, FRONT<br>STOP, LH.RH<br>TAIL, LH.RH<br>TURN SIGNAL, FRONT, LH.RH<br>TURN SIGNAL, REAR, LH.RH<br>TURN SIGNAL SIDE LH RH | E-19<br>G-22<br>C-15<br>E-9<br>D-9<br>D-14<br>C-8<br>E-12<br>G-21<br>C-17<br>E-11<br>B-2<br>D-12<br>E-16<br>C-9<br>E-14<br>E-10<br>D-21 | DIMMER<br>ENGINE OIL PRESSURE<br>FOG LIGHT (OPT)<br>FRONT DRIVE (OPT)<br>FRONT DRIVE INDICATOR LIGHT<br>HAZARD WARNING SIGNAL (OPT)<br>HEATER BLOWER (Except ECE OPT)<br>HORN<br>INTERIOR LIGHT<br>LIGHT CONTROL<br>PARKING BRAKE LIGHT (OPT)<br>STARTER<br>STOP LIGHT<br>TRAILER SOCKET CHANGEOVER (OPT)<br>TRANSFER INDICATOR (OPT)<br>TURN SIGNAL<br>VACUUM WARNING<br>WINDSHIELD WIPER & WASHER |
|   | MOTORS  | E-17  | THAILER SOCKET (OPT)  |
| E-8<br>C-3  | HEATER BLOWER (Except ECE OPT)<br>STARTER   | G-8<br>C-10   | VACUUM SWITCHING SOLENOID (OPT)<br>VACUUM WARNING BUZZER  |
| C-21  | WINDSHIELD WASHER (OPT)   | E-6   | WATER TEMPERATURE GAUGE   |
| F-21  | WINDSHIELD WIPER  | E-7   | WATER TEMPERATURE SENDER  |

## LAND CRUISER (BJ40, 43) ELECTRICAL WIRING DIAGRAM (Except U.S.A & CANADA) No. 98881

Note:

When reading the wiring diagram, following should be noted.
WIRING COLOR CODE IS SHOWN WITH ALPHABETICAL LETTER/S. THE FIRST LETTER INDICATES THE BASIC COLOR FOR THE WIRE, AND THE SECOND LETTER INDICATES THE SPIRAL LINE COLOR.

| E SPIRAL LINE CU | LUK. |
|------------------|------|
| B = BLACK        |      |
| G = GREEN        |      |

| O = ORANGE | W = WHITE  |
|------------|------------|
| R = RED    | Y = YELLOW |
|            |            |

L = LIGHT BLUE EXAMPLE: RG, IS FOR RED AND A GREEN LINE 2. LEGEND IN THE BRACKET [ ] OF THE WIRING DIAGRAM SHOWS THE GRID LOCATION OF MATING CONNECTION.

3. BROKEN LINES IN THE WIRING DIAGRAM ARE FOR VARIED MODELS OR OPTIONAL EQUIPMENT.









| GRIDE  | COMPONENTS  | GRIDE   | COMPONENTS  |
|--|---|---|---|
| E-3<br>C-5<br>D-21<br>C-4  | ALTERNATOR<br>AMMETER<br>ANTENNA (OPT)<br>BATTERY   | G-11<br>G-18<br>F-15<br>F-15<br>G-15                                      | STOP, LH · RH<br>TAIL, LH · RH<br>TURN SIGNAL, FRONT, LH · RH<br>TURN SIGNAL, REAR, LH · RH<br>TURN SIGNAL INDICATOR, LH · RH   |
| C-5  | COMBINATION METER   | G-4   | MAINTENANCE INTERVAL DETECTOR   |
| D-23   | DISTRIBUTOR   | De  | MOTORS:   |
| F-23<br>E-24<br>H-22<br>H-22<br>H-23<br>H-23                       | EMMISSION CONTROL SYSTEM:<br>3 EMISSION CONTROL COMPUTER<br>4 EMISSION INSPECTION CONNECTOR<br>2 SPEED SENSOR<br>2 THERMO SENSOR at EGR Valve<br>3 THERMO SENSOR at Carburetor<br>3 THERMO SENSOR at Carburetor | E-7<br>C-2<br>C-19<br>F-20<br>D-5<br>D-6                                  | HEATER BLOWER, FRONT (OPT)<br>HEATER BLOWER, REAR (OPT)<br>STARTER<br>WINDSHIELD WASHER<br>WINDSHIELD WIPER<br>OIL PRESSURE GAUGE<br>OIL PRESSURE SENDER  |
| H-22<br>E-22   | THROTTLE POSITION SWITCH<br>VACUUM SWITCHING VALVE  | C-20<br>F-3   | RADIO (OPT)<br>REGULATOR  |
| C-15<br>C-23<br>F-5  | ELASHER, TURN SIGNAL & HAZARD<br>FUEL CUT SOLENOID<br>FUEL GAUGE  | E-9<br>C-12   | RELAYS:<br>FRONT DRIVE (OPT)<br>HORN  |
| F-6  |   | D-20  | SPEAKER (OPT)   |
| C-4  | FUSIBLE LINK  | 07  | SWITCHES:   |
| G-13   | HORNS, LO-HI  | F-10  | BRAKE WARNING LIGHT   |
| D-22<br>C-23<br>G-20   | IGNITER<br>IGNITION COIL<br>INSPECTION LIGHT SOCKET   | E-16<br>E-10<br>C-10  | DIAMER<br>DIMMER<br>FRONT DRIVE (OPT)<br>FRONT DRIVE INDICATOR LIGHT<br>HAZARD WARNING LIGHT<br>HEATER BLOWER MOTOR (OPT)<br>HORN<br>IGNITION<br>INTERIOR LIGHT<br>LIGHT CONTROL<br>PANEL LIGHT CONTROL<br>PARKING BRAKE<br>STOP LIGHT<br>TRANSFER INDICATOR (OPT)<br>TURN SIGNAL |
| G-7<br>C-10<br>D-18<br>D-9<br>G-16<br>E-18<br>F-15<br>G-21<br>E-17 | LIGHTS:<br>BACK-UP, LH · RH<br>BRAKE WARNING INDICATOR<br>COMBINATION METER<br>FRONT DRIVE (OPT)<br>HEADLIGHT, LH · RH<br>HEATER CONTROL INDICATOR<br>HIGH BEAM INDICATOR<br>INTERIOR<br>LICENSE PLATE          | C-6<br>D-12<br>B-2<br>G-21<br>C-16<br>D-17<br>E-10<br>D-11<br>C-8<br>E-14 |   |
| 0-10   |   | D-19  | WINDSHIELD WIPER AND WASHER   |

LAND CRUISER (FJ 40 Series) ELECTRICAL WIRING DIAGRAM (For U.S.A. & CANADA) -1975 Model No. 98876

Note:

G-5

F-18 G-18

E-17

MAINTENANCE WARNING

PARKING, FRONT

MARKER, FRONT SIDE, LH · RH MARKER, REAR SIDE, LH · RH

 When reading the wiring diagram, following should be noted.
 1. WIRING COLOR CODE IS SHOWN WITH ALPHABETICAL LETTER/S. THE FIRST LETTER INDICATES THE BASIC COLOR FOR THE WIRE, AND THE SECOND LETTER INDICATES THE SPIRAL LINE COLOR.

F-8

E-5

E-6

VACUUM SWITCHING SOLENOID (OPT)

WATER TEMPERATURE GAUGE

WATER TEMPERATURE SENDER

| B = BLACK | O = ORANGE | W = WHITE  |
|-----------|------------|------------|
| G = GREEN | R = RED    | Y = YELLOW |
|           |            |            |

L = LIGHT BLUE EXAMPLE : RG, IS FOR RED AND A GREEN LINE. LEGEND IN THE BRACKET [ ] OF THE WIRING DIAGRAM SHOWS THE GRID LOCATION OF MATING CONNECTION. 2.

BROKEN LINES IN THE WIRING DIAGRAM ARE FOR VARIED MODELS OR OPTIONAL EQUIPMENT. 3.









## LAND CRUISER (FJ 55LG) ELECTRICAL WIRING DIAGRAM (For U.S.A & CANADA) -1975 Model No. 98877

| GRIDE<br>LOCATION   | COMPONENTS  | GRIDE<br>LOCATION   | COMPONENTS   |
|---|---|---|--|
| F-2<br>D-18   | ALTERNATOR<br>ANTENA (OPT)  | F-13<br>G-15  | TURN SIGNAL, FRONT, LH.RH<br>TURN SIGNAL, REAR, LH.RH  |
| D-3   | BATTERY   | G-13  | TURN SIGNAL INDICATOR, LH.RH   |
| C-20<br>E-3<br>C-4  | CIGARETTE LIGHTER (OPT)<br>CIRCUIT BRAKER<br>COMBINATION METER  | C-6<br>E-7  | MOTORS:<br>HEATER BLOWER, FRONT<br>HEATER BLOWER, REAR (OPT)   |
| D-4   | DISTRIBUTOR   | D-2   | STARTER  |
| G-22<br>E-21  | EMISSION CONTROL SYSTEM :<br>EMISSION CONTROL COMPUTER<br>EMISSION INSPECTION CONNECTOR   | C-20<br>F-20  | WINDSHIELD WASHER<br>WINDSHIELD WIPER  |
| C-22  | MAINTENANCE INTERVAL DETECTOR   | E-4   | OIL PRESSURE GAUGE   |
| F-23  | MAINTENANCE WARNING LIGHT   | E-5   | OIL PRESSURE SENDER  |
| G-21<br>G-21  | -21     SPEED SENSOR       -21     THREMO SENSOR at EGR Valve       -21     THERMO SENSOR at Carburetor       -21     THERMO SWITCH for Coolant Temp       -22     THROTTLE POSITION SWITCH       -23     VACUUM SWITCHING VALVE  | C-19<br>E-2   | RADIO (OPT)<br>REGULATOR   |
| G-21<br>F-21<br>G-22<br>F-23  |   | F-8<br>C-12<br>E-4  | RELAYS:<br>FRONT DRIVE (OPT)<br>HORN<br>TAIL GATE  |
| D-13<br>C-23  | FLASHER, TURN SIGNAL & HAZARD<br>FUEL CUT SOLENOID  | E-19  | SPEAKER (OPT)  |
| G-4<br>G-5<br>B-4<br>C-3  | FUEL GAUGE<br>FUEL SENDER<br>FUSE BOX<br>FUSIBLE LINK   | D-10<br>E-11<br>E-17  | SWITCHS:<br>BACK-UP LIGHT<br>BRAKE WARNING<br>DIMMER   |
| D-12  | HORNS, LO-HI  | E-9   | FRONT DRIVE (OPT)  |
| C-4<br>C-3<br>E-21  | IGNITER<br>IGNITION COIL<br>INSPECTION LIGHT SOCKET   |   | FRONT DRIVE INDICATOR LIGHT<br>HAZARD WARNING LIGHT<br>HEATER BLOWER, FRONT  |
| G-9<br>D-10<br>E-17<br>D-4<br>E-9<br>G-18<br>E-17<br>F-18<br>D-21<br>D-15<br>D-16<br>E-16<br>F-16<br>F-16<br>E-15<br>C-15 | LIGHTS:<br>G-9 BACK-UP, LH, RH<br>D-10 BRAKE WARNING INDICATOR<br>E-17 COMBINATION METER PILOT<br>D-4 DISCHARGE WARNING<br>E-9 FRONT DRIVE INDICATOR<br>G-18 HEADLIGHT, LH.RH<br>E-17 HEATER CONTROL INDICATOR<br>F-18 HIGH BEAM INDICATOR<br>D-11 INTERIOR<br>D-15 LICENSE PLATE<br>D-16 LIGHT CONTROL SWITCH<br>E-16 MARKER, FRONT SIDE, LH.RH<br>F-16 MARKER, REAR SIDE, LH.RH<br>E-15 PARKING, FRONT<br>G-15 STOP LH RH | C-7<br>D-12<br>B-1<br>D-21<br>D-16<br>D-11<br>C-11<br>F-3<br>F-4<br>G-3<br>C-8<br>E-13<br>E-19<br>G-7 | HEATER BLOWER, REAR (OPT)<br>HORN<br>IGNITION<br>INTERIOR LIGHT<br>LIGHT CONTROL<br>PARKING BRAKE<br>STOP LIGHT<br>TAIL GATE CONTROL<br>TAIL GATE REMOTE CONTROL<br>TAIL GATE SAFETY<br>TRANSFER INDICATOR (OPT)<br>TURN SIGNAL<br>WINDSHIELD WIPER AND WASHER<br>VACUUM SWITCHING SOLENOID (OPT)<br>WATER TEMPERATURE GAUGE |
| G-15<br>G-16  |   | F-4<br>F-5  | WATER TEMPERATURE SENDER   |

Note:

When reading the wiring diagram, following should be noted.
1. WIRING COLOR CODE IS SHOWN WITH ALPHABETICAL LETTER/S. THE FIRST LETTER INDICATES THE BASIC COLOR FOR THE WIRE, AND THE SECOND LETTER INDICATES

 

 THE FIRST LETTER INDICATES THE BASIC COLOR FOR THE WIRE, AND THE SECOND LETTER INDICATES

 THE SPIRAL LINE COLOR

 B = BLACK
 O = ORANGE
 W = WHITE

 G = GREEN
 R = RED
 Y = YELLOW

 L = LIGHT BLUE
 EXAMPLE : RG, IS FOR RED AND A GREEN LINE.

 LEGEND IN THE BRACKET [] OF THE WIRING DIAGRAM SHOWS THE GRID LOCATION OF MATING

 2.

CONNECTION. BROKEN LINES IN THE WIRING DIAGRAM ARE FOR VARIED MODELS OR OPTIONAL EQUIPMENT. 3.









